

**NATURAL RESOURCES CONSERVATION SERVICE
CONSERVATION PRACTICE STANDARD**

CONTOUR FARMING

(Ac.)

CODE 330

DEFINITION

Using ridges and furrows formed by tillage, planting and other farming operations to change the direction of runoff from directly downslope to around the hillslope.

When the row grade reaches the maximum allowable design grade, a new baseline shall be established up or down slope from the last contour line and used for layout of the next contour pattern.

PURPOSE

This practice is applied to achieve one or more of the following:

- Reduce sheet and rill erosion.
- Reduce transport of sediment, other solids, and the contaminants attached to them.
- Increase water infiltration.

Minimum Ridge Height.

Row spacing greater than 10 inches. The minimum ridge height shall be two inches during the period of the rotation that is most vulnerable to sheet and rill erosion. Ridge height will be determined using the current approved erosion prediction technology.

CONDITIONS WHERE PRACTICE APPLIES

This practice applies on sloping land where annual crops are grown. For orchards, vineyards, and nut crops, use the Conservation Practice Standard (CPS) Contour Orchard and Other Fruit Areas (331).

Row spacing 10 inches or less. The minimum ridge height shall be one inch for close-grown crops, such as small grains. Plant height shall be at least six inches high and the spacing between plants within the row shall not be greater than two inches during the time most vulnerable to sheet and rill erosion.

CRITERIA

General Criteria Applicable to All Purposes

Minimum Row Grade. The crop rows shall have sufficient grade to ensure that runoff water does not pond and cause unacceptable crop damage.

Maximum Row Grade. The maximum row grade shall not exceed two percent or one-half of the up-and-down hill slope percent used for conservation planning, whichever is less.

Up to 3 percent row grade is permitted within 150 feet of a stable outlet.

The minimum ridge height criteria are not required when the CPS Residue and Tillage Management, No Till/Strip Till/Direct Seed (329) is used on the contour and at least 50 percent surface residue cover is present between the rows after planting.

Stable Outlets. Surface flow from contoured fields shall be delivered to stable outlets. Stable outlets include grassed waterways, underground outlets for terraces or diversions, water and sediment control basins, field borders, or similarly stabilized areas.

Additional Criteria to Increase Water Infiltration

Row Grade. The maximum row grade shall not exceed 0.2 percent.

CONSIDERATIONS

Contour farming is most effective on slopes between 2 and 10 percent. This practice will be less effective in achieving the stated purpose(s) on slopes exceeding 10 percent and in areas with 10-year, 24-hour rainfall of about 6.5 inches. The practice is not well suited to rolling topography having a high degree of slope irregularity because of the difficulty meeting row grade criteria.

This practice is most effective on slopes between 100 and 400 feet long. On slopes longer than 400 feet, the volume and velocity of overland flow exceeds the capacity of the contour ridges to contain them. Increasing residue cover and roughness will change the vegetative cover-management conditions and decrease overland flow velocities, thus increasing the slope length at which this practice is effective. Increasing roughness alone is not sufficient to produce this effect.

The closer the row grade is to the true contour, the greater will be the erosion reduction.

Prior to design and layout, obstruction removal and changes in field boundaries or shape should be considered, where feasible, to improve the effectiveness of the practice and the ease of performing farming operations.

When the intersection of crop rows with the field edge is not perpendicular, a field border may be needed to allow farm implements room to turn.

If using CPS Residue and Tillage Management, Ridge Till (346) on the contour, avoid crossing over ridged rows at correction areas because this will destroy the effectiveness of the ridges. Sod turn strips may be established if correction areas are unavoidable.

The width of correction areas and the distance between baselines should be adjusted for equipment operation widths.

Ridge Height. Ridge height is created by the operation of tillage and planting equipment. The greater the ridge height, the more effective the operation is in slowing overland flow. The Revised Universal Soil Loss Equation

(RUSLE2) Operations database contains the ridge height value for each field operation.

PLANS AND SPECIFICATIONS

Specifications for establishment and operation of this practice shall be prepared for each field according to the Criteria, Considerations, and Operation and Maintenance described in this standard. The plans shall include, as a minimum:

- Percent land slope used for conservation planning;
- The minimum and maximum allowable row grades for the contour system;
- A sketch map or photograph of the field showing:
 - the approximate location of the baselines used to establish the system;
 - the location of stable outlets for the system.

Specifications shall be recorded using approved specification sheets, job sheets, narrative statements in the conservation plan, or other acceptable documentation.

OPERATION AND MAINTENANCE

Perform all tillage and planting operations parallel to contour baselines or terraces, diversions, or contour buffer strip boundaries where these practices are used, provided the applicable row grade criteria are met.

Where terraces, diversions, or contour buffer strips are not present, maintain contour markers on grades that, when followed during establishment of each crop, will maintain crop rows at designed grades. Contour markers may be field boundaries, a crop row left untilled near or on an original contour baseline or other readily identifiable, continuous, lasting marker. All tillage and planting operations shall be parallel to the established marker. If a marker is lost, re-establish a contour baseline within the applicable criteria set forth by this standard prior to seedbed preparation for the next crop.

Farming operations should begin on the contour baselines and proceed both up and

down the slope in a parallel pattern until patterns meet. Where field operations begin to converge between two nonparallel contour baselines, establish a correction area that either is permanently in sod, or established to an annual close-grown crop.

Where contour row curvature becomes too sharp to keep machinery aligned with rows during field operations, establish sod turn strips on sharp ridge points or other odd areas as needed.

REFERENCES

Foster, G.R. Revised Universal Soil Loss Equation, Version 2 (RUSLE2) Science Documentation (In Draft). USDA-ARS, Washington, DC. 2005.

Renard, K.G., G.R. Foster, G.A. Weesies, D.K. McCool, and D.C. Yoder, coordinators. 1997. Predicting soil erosion by water: A guide to conservation planning with the Revised Universal Soil Loss Equation (RUSLE). U.S. Department of Agriculture, Agriculture Handbook 703.