

NATURAL RESOURCES CONSERVATION SERVICE
CONSERVATION PRACTICE STANDARD

TERRACE

(Feet)

Code 600



DEFINITION

An earth embankment, or a combination ridge and channel constructed across the field slope.

PURPOSE

This practice is applied as part of a resource management system for one or more of the following purposes:

- Reduce soil erosion by reducing slope length.
- Retain runoff for moisture conservation.

CONDITIONS WHERE PRACTICE APPLIES

This practice applies where:

- Soil erosion caused by water and excessive slope length is a problem.
- Excess runoff is a problem.
- There is a need to conserve water.
- The soils and topography are such that terraces can be constructed and reasonably farmed.
- A suitable outlet can be provided.

CRITERIA

General Criteria Applicable To All Purposes

All planned work shall comply with Federal, state, and local laws, rules and regulations. Plans for terraces may need to be permitted by the appropriate Water Management District (WMD) and comply with the appropriate WMD rules contained in Chapter 40-4 Florida Administrative Code (F.A.C.), Environmental Resource Permits: Surface Water Management Systems; Chapter 40-40 F.A.C., Standard General Environmental Resource Permits: Regulation of Stormwater Management Systems; Chapter 40-41 F.A.C., Environmental Resource Permits: Surface Water Management Basin Criteria; Chapter 40-42 F.A.C., Environmental Resource Permits: Regulation of Stormwater Management Systems; Chapter 40-44 F.A.C., Environmental Resource Permits: Regulation of Agricultural Surface Water Management Systems.

Impact to cultural resources, wetlands and Federal and state protected species shall be evaluated and avoided or minimized to the extent practicable during planning, design and implementation of this conservation practice in accordance with established National and Florida policy, General Manual (GM) Title 420-Part 401; Title 450-Part 401, Title 190-Parts 410.22 and 410.26, National Planning Procedures Handbook (NPPH) Florida Supplements to Parts 600.1 and 600.6, National Cultural Resources Procedures Handbook (NCRPH), National Food Security Act Manual (NFSAM), and the National Environmental Compliance Handbook (NECH).

Spacing. Space terraces at intervals across the slope to achieve the intended purpose. The maximum spacing of terraces for erosion control is that necessary to achieve soil loss tolerance (T). Include both the terrace system with planned as-built slopes and cultural practices such as residue management when determining

Conservation practice standards are reviewed periodically, and updated if needed. To obtain the current version of this standard, contact the Natural Resources Conservation Service.

soil loss. The slope length used when checking soil loss for a proposed terrace spacing is the distance from the terrace ridge to the next lower terrace channel measured along the natural flow direction. Maximum spacing for erosion control based on soil loss tolerance may be increased by as much as 10 percent to provide better location, alignment to accommodate farm machinery, or to reach a satisfactory outlet.

The methods that may be used to determine terrace spacing include the current NRCS accepted erosion prediction technology or the Vertical Interval Equation. Refer to the current NRCS accepted erosion prediction software and user guide to determine soil loss. Refer to the NRCS National Engineering Handbook, Part 650, Engineering Field Handbook, Chapter 8, Terraces for use of the Vertical Interval Equation.

Alignment. To accommodate farm machinery and farming operations, design cropland terraces with long gentle curves. When multiple terraces are used in a field, design the terraces to be as parallel to one another as practicable.

Capacity. Design terraces to have enough capacity to control the runoff from a 10-year frequency, 24-hour storm without overtopping. For terrace systems designed to control excess runoff or to function with other structures, choose a larger design storm that is appropriate to the risk associated with the installation. For terraces with underground outlets, the capacity to contain the design storm can be a combination of storage and out flow through the underground outlet. Increase the capacity of terraces by the estimated 10-year sediment accumulation, unless the Operation and Maintenance Plan specifically addresses the annual removal of sediment.

For terraces with open outlets, the capacity is based on the terrace channel size and stability. Base the capacity of the channel on a bare earth channel for crop fields or in the case of a permanently vegetated channel, the appropriate vegetation. For bare earth channels use a Manning's n value of 0.035 or greater to calculate capacity. For permanently vegetated channels refer to Florida NRCS conservation practice standard Grassed Waterway, Code 412 for design criteria to determine capacity.

Design level terraces to contain the runoff from a 10-year 24-hour rainfall event, and the expected 10-year sediment accumulation, unless the Operation and Maintenance Plan specifically addresses the annual removal of sediment.

Terrace cross section. Proportion the terrace cross section to fit the land slope, the crops grown, and the farm machinery used. Add ridge height if necessary to provide for settlement, channel sediment deposits, ridge erosion, the effect of normal tillage operations, or safety. At the design elevation, the ridge shall have a minimum width of 3 feet. For terraces with open outlets, design the capacity of the outlet to be equal to or greater than the capacity of the terrace channel.

All farmable terrace slopes shall be no steeper than those on which farm equipment can be operated safely. For non-farmable terrace slopes, the steepest slopes allowable are 2 horizontal to 1 vertical (2:1) unless an analysis of site specific soil conditions indicate that steeper slopes will be stable.

End closures. Level terraces may have open ends, partial end closures, or complete end closures. Use partial and complete end closures only on soils and slopes where stored water will be absorbed by the soil without appreciable crop damage or where underground outlets are provided.

If terraces with closed or partly closed ends are specified, install the end closures before the terraces are completed. End closures less than or equal to half the effective height of the terrace ridge are considered partial closures while those greater than half the height are considered complete closures. The cross-sectional area of the end closure fill may be less than the terrace cross section. For level terraces that have end closures that are lower than the terrace ridge elevation, areas downstream from the end closure must be protected from flow that will exit from the closure before the design storm is reached.

Channel grade. Design the terrace channel to be stable with non-erosive velocities but with sufficient grade to prevent damage to crops or to prevent delay of farming activities from prolonged ponding.

For cultivated terraces, base the channel stability on a bare earth condition. The maximum velocity for erosion-resistant soils is 2.5 ft/s (clay textural classification); for average soils, 2.0 ft/s (silt textural classification); and for easily erodible soils, 1.5 ft/s (sand textural classification). If Manning's equation is used to compute velocity, use a maximum n value of 0.035 to determine velocity for channel stability.

For permanently vegetated channels, base the channel stability on the appropriate vegetation. Refer to Florida NRCS conservation practice standard Grassed Waterway, Code 412 for design criteria to determine stability.

For short distances and in the upper reaches of a channel, grades may be increased to improve alignment. For terraces with an underground outlet, channel grades can be steeper for short distances within the impoundment area.

Level terrace length. The volume of water stored in level terraces is proportional to the length. To reduce the potential risk from failure, do not design level terraces with lengths that exceed 3,500 feet unless the channel is blocked at intervals not exceeding 3,500 feet.

Outlets. All terraces must have adequate outlets. The outlet must convey runoff water to a point where it will not cause damage.

Vegetated outlets are suitable for gradient or open-end level terraces. Grassed waterways or naturally vegetated drainage ways may be used as a vegetated outlet. Install and stabilize grassed waterways prior to the construction of the terrace so that the terrace will have a stable outlet when it is constructed. The capacity of the vegetated outlet must be large enough so that the water surface in the outlet is below the water surface in the terrace at design flow.

Underground outlets are suitable on gradient or level terraces. The outlet consists of an intake and an underground conduit. Refer to Florida NRCS conservation practice standard Underground Outlet, Code 620 for design criteria for the underground outlet.

Design the intake structure for the underground outlet to control the flow out of the terrace and to prevent excessive pressure in the underground conduit. Design the outlet so that the flow release time does not exceed the inundation tolerance of the planned crops. If sediment retention is a primary design goal, adjust the release rate according to sediment particle size. Locate the inlet for the underground outlet to accommodate farming operations and to allow for sediment accumulation.

Soil infiltration may be used as the outlet for level terraces. Soil infiltration rates, under average rainfall conditions, must permit infiltration of the design storm from the terrace channel within the inundation tolerance of the planned crops.

Combinations of different types of outlets may be used on the same system to optimize water conservation, improve water quality, accommodate farming operations or to provide for economical installation.

Vegetation. Stabilize all areas planned for vegetation as soon as possible after construction. Refer to Florida NRCS conservation practice standard Critical Area Planting, Code 342, for seeding criteria.

Drainage. Install subsurface drainage to stabilize soils and improve terrace function as needed. Refer to Florida NRCS conservation practice standard Subsurface Drain, Code 606 for design and installation criteria.

Additional Criteria Applicable To Retaining Runoff For Moisture Control

For terraces installed to retain moisture, perform a water budget analysis to determine the volume of water that must be collected to meet the requirements of the water budget. As a minimum the terrace must still meet the design storm and sediment volume requirements in the Capacity Section of this standard.

CONSIDERATIONS

One of the keys to a successful terrace system is to make sure that the terrace layout fits the farm equipment. This includes making curves long and gentle and spacing terraces so that the operator can make an even number of trips between terraces so that they end up on the same side of the field they started on.

Terrace ridges and cut slopes can introduce steep and potentially hazardous slopes into a crop field. Where slopes will be farmed, make sure they can be safely negotiated with the operator's equipment. Where steep slopes are unavoidable make sure the operator is aware of the location and potential danger of the slopes.

The soil survey can be a valuable resource when planning and designing terrace systems. The soil survey can identify potential problems such as the presence of limiting layers to plant growth in the soil profile. Field investigations can then identify problem areas to avoid such as shallow bedrock or dense, acid or saline layers that will adversely affect plant growth if construction brings them into the root zone.

Steep sided terraces that are in permanent vegetation can provide significant areas of habitat for wildlife. Consider planting native

species that provide food and cover for wildlife. Do not mow these areas until after the nesting season to improve wildlife production.

Hillside seeps in a crop field can cause cropping problems. Consider aligning terraces and/or installing subsurface drainage to intercept and correct seepage problems.

Erosion can be a problem at the outfall of an underground outlet. To ensure an adequate outlet, protect the outfall of the underground outlet so that it is stable.

Outlets from terraces can provide a direct conduit to receiving waters for contaminated runoff from crop land. Terraces should be installed as part of a conservation system that addresses issues such as nutrient and pest management, residue management and filter areas.

Inlets for underground outlets can be easily damaged during cultivation, planting and harvesting operations. Using brightly colored inlets, barriers around the inlet or otherwise clearly marking the inlet will help prevent damage.

For terraces that will be farmed or otherwise revegetated, the stripping and stockpiling of topsoil from the construction area prior to excavation and then spreading the topsoil on the completed terrace will improve the growth of vegetation after construction.

PLANS AND SPECIFICATIONS

Plans and specifications for terraces shall be in keeping with this standard and shall describe the requirements for applying the practice to achieve its intended purpose.

As a minimum, the plans and specifications shall include:

1. A plan view of the layout of the terrace system.
2. Typical cross sections of the terrace(s).
3. Profile(s) or planned grade of the terrace(s).
4. Details of the outlet system.
5. If underground outlets are used, details of the inlet and profile(s) of the underground outlet.
6. Seeding requirements if needed.

7. Site specific construction specifications that describe in writing the installation of the terrace system.

OPERATION AND MAINTENANCE

Prepare an operation and maintenance plan for the operator. The minimum requirements to be addressed in a written operation and maintenance plan are:

1. Periodic inspections, especially immediately following significant runoff events.
2. Prompt repair or replacement of damaged components.
3. Maintenance of terrace ridge height, channel profile, terrace cross-sections and outlet elevations.
4. Removal of sediment that has accumulated in the terrace channel to maintain capacity and grade.
5. Regular cleaning of inlets for underground outlets. Repair or replacement of inlets damaged by farm equipment. Removal of sediment around inlets to ensure that the inlet remains the lowest spot in the terrace channel.
6. Where vegetation is specified, seasonal mowing and control of trees and brush.
7. Notification of hazards about steep slopes on the terrace.

REFERENCES

- Agricultural Handbook Number 667, Stability Design of Grass-lined Open Channels
Florida NRCS Conservation Practice Standards:
Critical Area Planting, Code 342
Grassed Waterway, Code 412
Subsurface Drain, Code 606
Underground Outlet, Code 620
- General Manual
Title 420-Part 401
Title 450-Part 401
Title 190-Parts 410.22 and 410.26
- National Cultural Resources Handbook
National Engineering Handbook, Part 650,
Engineering Field Handbook, Chapter 8
National Environmental Compliance Handbook
National Food Security Act Manual
National Planning Procedures Handbook
Florida Supplements to Parts 600.1 and 600.6
WMD Rules Chapters 40-4, 40-40, 40-41, 40-42, 40-44 F.A.C.