



Notes:
 Horizontal brace member: place 8"-12" below top of fence post; minimum 8 feet long.

Use two loops of the following wire to tension brace:
 9 gauge galvanized, 12.5 gauge high tensile wire.
 Barbed wire may be used on barbed wire fences.

Tension wires using metal or treated wood twitch sticks or in-line strainers.

WOODEN BRACE POST ATTACHMENT GUIDELINES

File Name _____
 Drawing Name
 AL-ECS-382-21
 00/00/00 00:00
 Sheet of

Date _____
 Designed _____
 Drawn _____
 Checked _____
 Approved _____ 5/16

