

**NATURAL RESOURCES CONSERVATION SERVICE
CONSERVATION PRACTICE STANDARD**

STREAM CROSSING

(No.)

CODE 578

DEFINITION

A stabilized area or structure constructed across a stream to provide a travel way for people, livestock, equipment, or vehicles.

PURPOSE

- Provide access to another land unit
- Improve water quality by reducing sediment, nutrient, organic, and inorganic loading of the stream
- Reduce streambank and streambed erosion

CONDITIONS WHERE PRACTICE APPLIES

This practice applies to all land uses where an intermittent or perennial watercourse exists and a ford, bridge, or culvert type crossing is needed.

CRITERIA

Apply this standard in accordance with all local, State, Tribal, and Federal regulations, including flood plain regulations and flowage easements.

Identify significant cultural resources or threatened or endangered species that could be affected by the implementation of the practice.

Location. Locate stream crossings in areas where the streambed is stable or where it can be stabilized (see Alabama NRCS Conservation Practice Standard, Channel Bed Stabilization, Code 584). Do not place crossings where channel grade or alignment changes abruptly, excessive seepage or instability is evident, overfalls exist (evidence of incision and bed instability), where large tributaries enter the stream, or within 300 feet of known spawning areas of listed species. Avoid wetland areas.

Discourage livestock loafing in the stream by locating crossings, where possible, out of shady riparian areas or by including gates in the design.

Minimize shade by selectively removing trees and pruning limbs where appropriate.

Install stream crossings perpendicular to the direction of stream flow where possible. Fully consider the natural lateral migration pattern of the stream in the design. Avoid skews on all but the smallest streams.

Access Roads. Where the stream crossing is installed as part of a roadway, size the crossing according to the Alabama NRCS Conservation Practice Standard, Access Road, Code 560. Where high rates of erosion of the adjacent roadways that slope towards the crossing threaten to deliver an excessive amount of sediment to the drainage, install measures to minimize erosion of the roadside ditch, road surface, and/or cut slopes.

Width. Provide an adequate travel-way width for the intended use. "Livestock- only" crossings shall be no less than 6 feet wide. A multi-use stream crossing shall have a travel-way no less than 10 feet wide and no more than 20 feet wide. Width is measured from the upstream end to the downstream end of the stream crossing, not including the side slopes.

Side Slopes. Make all side slope cuts and fills stable for the channel materials involved. Make the side slopes of cuts or fills in soil materials no steeper than 2.5 horizontal to 1 vertical (2.5:1). Make rock cuts or fills no steeper than 1.5 horizontal to 1 vertical (1.5:1).

Stream Approaches. Blend approaches to the stream crossing with existing site conditions, where possible. Use streambank soil bioengineering practices as appropriate and feasible. Make the approaches stable, with gradual ascent and descent grades which are not steeper than 5 horizontal to 1 vertical (5:1), and of suitable material to withstand repeated and long term use. Make the minimum width of the approaches equal to the width of the crossing surface.

Divert surface runoff around the approaches to prevent erosion. Direct roadside ditches into a diversion or away from the crossing surface.

Configure the crossing approaches (gradient and curves) to properly accommodate the length and turning radii of vehicles using the crossing.

Rock. All rock must be able to withstand exposure to air, water, freezing, and thawing. Use rock of sufficient size and density to resist mobilization by design flood flows.

Use appropriate rock sizes to accommodate the intended traffic without damage to the livestock, people, or vehicles using the crossing.

Fencing. Exclude livestock access to the crossing through the use of fence and gates, as needed.

Install cross-stream fencing at fords, with breakaway wire, swinging floodgates, hanging electrified chain, or other devices to allow the passage of floodwater and large woody material during high flows.

Design and construct all fencing in accordance with Alabama NRCS Conservation Practice Standard, Fence, Code 382.

Vegetation. Plant all areas to be vegetated as soon as practical after construction. If completion does not coincide with appropriate planting dates for permanent cover, use a cover of temporary vegetation to protect the site until permanent cover can be established. Native or functioning-as-native plant species are preferred. Use Alabama NRCS Conservation Practice Standard, Critical Area Planting, Code 342, where vegetation is unlikely to become established by natural regeneration, or where acceleration of the recovery of vegetation is desired.

In areas where the vegetation may not survive, use Alabama NRCS Conservation Practice Standard, Heavy Use Area Protection, Code 561.

Bridge Crossings

Design bridges in a manner that is consistent with sound engineering principles and adequate for the use, type of road, or class of vehicle. Design bridges with sufficient capacity to convey the design flow and transported material without appreciably altering the stream flow characteristics. Design bridges to fully span the stream, passing at least the bankfull flow where the design flow is not dictated by regulation.

Bankfull flow is the discharge that fills a stream channel up to the elevation at which flow begins to spill onto the floodplain.

Adequately protect bridges protected so that out-of-bank flows safely bypass without damaging the bridge or eroding the banks.

Vehicle and pedestrian bridges must be designed in accordance with the current American Association of State Highway and Transportation Officials Load and Resistance Factor Design (LRFD) bridge design specifications (AASHTO, 2010), or according to Design Guide AL#1, BRIDGES FOR LIVESTOCK AND AGRICULTURAL EQUIPMENT.

Evaluate the need for safety measures such as guardrails and reflectors at bridge crossings.

Acceptable bridge materials include concrete, steel, and wood.

Culvert Crossings

Design culverts in a manner that is consistent with sound engineering principles and adequate for the use, type of road, or class of vehicle. For culverts associated with a road, culvert design flow shall meet the criteria in Alabama NRCS Conservation Practice Standard, Access Road, Code 560. The design flow for culverts not associated with a road will be the 2-year, 24-hour storm discharge, or bankfull flow, whichever is less. Design culverts with sufficient capacity to convey the design flow and transported material without appreciably altering the stream flow characteristics.

Design culverts to minimize habitat fragmentation and to minimize barriers to aquatic organism movement.

Do not use culverts where large flows of sediment or large woody material are expected, or where the channel gradient exceeds 6 percent (100 horizontal to 6 vertical).

Evaluate the need for safety measures such as guardrails at culvert crossings.

Crossings shall be adequately protected so that out-of-bank flows safely bypass without damaging the structure or eroding the streambanks or the crossing fill.

At least one culvert pipe shall be placed with its entire length set 6 in. below the existing stream bottom. Additional culverts may be used at various elevations to maintain terrace or floodplain hydraulics and water surface elevations.

Make the barrel length of the culvert adequate to extend the full width of the crossing, including side slopes, and inlet or outlet extensions.

Compacted fill will be used to form the culvert crossing. The minimum depth of compacted fill over the culvert shall be equal to one-half the diameter of the culvert, or 24 inches, whichever is greater. The compacted fill shall be built up over the culvert so that any stream overflow will cross the road at a point away from the culvert. The compacted fill and pipe outlet shall be protected from erosion if needed with riprap. The total thickness of riprap shall be at least 18 inches. A concrete headwall or grouted riprap may be required in cases of severe attack. The driving surface over culverts shall be topped with Class II non-woven geotextile and a minimum 6 inches of AASHTO No. 1 coarse aggregate or other suitable materials.

Acceptable culvert materials include concrete, corrugated metal, corrugated plastic, new or used high quality steel, and any other materials that meet the requirements of Alabama NRCS Conservation Practice Standard, Structure for Water Control, Code 587.

Ford Crossings

The following criteria apply to all ford crossings:

Make the cross-sectional area of the crossing equal to or greater than the natural channel cross-sectional area. Make a portion of the crossing depressed at or below the average stream bottom elevation when needed to keep base flows or low flows concentrated.

Match ford shape to the channel cross-section to the extent possible.

Provide cutoff walls at the upstream and downstream edges of ford-type stream crossings when needed to protect against undercutting.

Evaluate the need for water depth signage at ford crossings.

Where rock is used for ford-type stream crossings for livestock, use a hoof contact zone of small crushed aggregate over the rock. This zone could include crushed limestone, rock screenings, crusher run, or similar materials and shall cover the entire rock surface. Generally, 4 inches of hoof contact zone is necessary. This material does not have to meet any velocity criteria. This layer is expected to be replaced periodically by the landowner as livestock traffic or runoff events erode the surface material.

The top finished surface of the ford crossing shall follow the contours of the stream bottom.

Concrete Fords

Concrete ford crossings will only be approved by the state conservation engineer.

Use concrete ford crossings only where the foundation of the stream crossing is determined to have adequate bearing strength.

Use concrete with a minimum compressive strength of 3,000 psi at 28 days, with a ratio of water to cementitious materials of 0.50 or less. Use coarse aggregate of 0.75 to 1 inch nominal size. If designed for freezing conditions, use concrete with 4 to 8 percent air-entrainment.

Use a minimum thickness of 5 inches of placed concrete. Pour the concrete slab on a minimum 4-inch thick gravel base, unless the foundation is otherwise acceptable.

Construct toe-walls at the upstream and downstream ends of the crossing. Make the toe-walls a minimum of 6 in. thick and 18 in. deep. Extend the toe-walls in the stream approaches to the bankfull flow elevation.

Precast concrete panels may be used in lieu of cast-in-place concrete slabs. To the extent possible, the panels shall follow the contours of the stream bottom in order to avoid potential problems with sediment accumulation. Use concrete units that have adequate reinforcement for transportation and placement.

Dewatering of the site and toe-walls is required during placement of the concrete to maintain the proper water/cement ratio. Flowing water will erode concrete that is not sufficiently hardened. The stream must be diverted or retained from flowing over the concrete for at least 12 hours after placement of the concrete.

During construction, aquatic species must be removed from the construction area according to State protocols.

Rock Fords and the Use of Geosynthetics

Rock (riprap) ford crossings are often used in steep areas subject to flash flooding and where normal flow is shallow or intermittent. When the site has a soft or unstable subgrade, use geotextiles in the design of rock ford crossings. Geotextile filter cloth shall be a non-woven, needle-punched geotextile material with a minimum tensile strength of 120 pounds.

Dewater and excavate the bed of the channel to the necessary depth and width and cover with geotextile material. Install the geotextile material on the excavated surface of the ford and extend it across the bottom of the stream and at least up to the bankfull flow elevation.

Cover the geotextile material with at least 8 in. of crushed rock. Use minimum 6-inch deep geocells, if geocells are used. Geocell material shall not be used if velocities are expected to exceed 5 fps. Use durable geosynthetic materials and install them according to the manufacturer's recommendations, including the use of staples, clips, and anchor pins.

Design all rock ford stream crossings to remain stable for the bankfull flow. Compute channel velocities and choose rock size using procedures in NEH630; NEH654 TS14N; and EFH Chapter 16 (NEH650), Appendix 16A, or using the Alabama Worksheet for Geotextile and Stone Stream Crossing.

Where rock is used for ford crossings for livestock, use a hoof contact zone or alternative surfacing method over the rock.

The stream crossing must be designed to remain stable during either the bank full event or the peak runoff from a 10-year, 24-hour event, whichever is less. Channel velocities shall be computed or measured, and a stone size chosen from Table 578-1.

TABLE 578-1. MAXIMUM VELOCITY AND D₅₀ SIZES	
MAXIMUM VELOCITY (FPS)	D₅₀ * (INCHES)
2.7	0.5
3.2	1.0
4.3	2.0
5.3	3.0
6.3	4.0
*DIAMETER OF STONE SUCH THAT 50% (BY WEIGHT) OF THE STONES ARE SMALLER.	

When larger stone than D₅₀ of 4 in. is used for convenience, the minimum thickness will be 1.5 x D₅₀.

NRCS, AL
July 2012

CONSIDERATIONS

Avoid or minimize the use of or number of stream crossings, when possible, through evaluation of alternative trail or travel-way locations. Assess landuser operations to consolidate and minimize the number of crossings. Where feasible, use existing roads.

Evaluate proposed crossing sites for variations in stage and discharge, tidal influence, hydraulics, fluvial geomorphic impacts, sediment transport and flow continuity, groundwater conditions, and movement of woody and organic material. Increase crossing width or span to accommodate transport of large woody material in the flow. Design passage features to account for the known range of variation.

For culvert crossings, consider incorporating natural streambed substrates throughout the culvert length for passage of aquatic organisms (see Bunt and Abt, 2001, for sampling procedures). Natural streambeds provide passage and habitat benefits to many life stage requirements for aquatic organisms and may reduce maintenance costs.

Consider all life stages of aquatic organisms in the stream crossing design to accommodate their passage, in accordance with the species' requirements. Design criteria are available in NEH Part 654, Technical Supplement 14N, Fish Passage and Screening Design; U.S Forest Service low-water design guidance (USFS, 2006); and stream simulation guidance (USFS, 2008). See also Harrelson, et al. 1994, for stream reference site descriptions.

Where a stream crossing is installed to remove an existing barrier to the passage of aquatic organisms, consider using National NRCS Conservation Practice Standard, Aquatic Organism Passage, Code 396.

Consider relevant aquatic organisms in the design and location of crossings to improve or provide passage for as many different aquatic species and age classes as possible.

Consider the habitat requirements of other aquatic or terrestrial species that may be affected by construction of a stream crossing. For example, a crossing may be designed with features that also promote safe crossing by terrestrial vertebrates.

Ford crossings have the least detrimental impact on water quality when their use is infrequent. Ford crossings are adapted for crossing wide, shallow

watercourses with firm streambeds. If the stream crossing is to be used frequently, or daily, as in a dairy operation, a culvert crossing or curbed bridge should be used, rather than a ford crossing.

Locate stream crossings to avoid adverse environmental impacts and consider the following:

- Effects on upstream and downstream flow conditions that could result in increases in erosion, deposition, or flooding. Consider habitat upstream and downstream of the crossing to avoid fragmentation of aquatic and riparian habitats.
- Short-term and construction-related effects on water quality.
- Overall effect on erosion and sedimentation that will be caused by the installation of the crossing and any necessary stream diversion.
- Effects of large woody material on the operation and overall design of the crossing.
- Consider adding a well-graded rock riprap apron on the downstream edge of concrete crossings to dissipate flow energy.
- Ford crossings should not be placed immediately downstream from a pipe or culvert because of potential damage from localized high velocity flows.

PLANS AND SPECIFICATIONS

Prepare plans and specifications for stream crossings in keeping with this standard. The plans and specifications must clearly describe the requirements for applying the practice to achieve its intended purpose.

As a minimum, include the following in plans and specifications:

- Location of stream crossing.
- Stream crossing width and length with profile and typical cross sections.
- Design grades or slopes of stream approaches.
- Design flow calculations.

- Thickness, gradation, quantities, and type of rock or stone.
- Type, dimensions, and anchoring requirements of geotextile.
- Thickness, compressive strength, reinforcement and other special requirements for concrete, if used.
- Vegetative requirements that include seed and plant materials to be used, establishment rates, and season of planting.
- Location, type, and extent of fencing required.
- Method of surface water diversion and dewatering during construction.
- Location of utilities and notification requirements.

OPERATION AND MAINTENANCE

Develop an operation and maintenance plan and implement it for the life of the practice.

Include the following items in the operation and maintenance plan, as a minimum:

- Inspect the stream crossing, appurtenances, and associated fence after each major storm event and make repairs if needed.
- Remove any accumulation of organic material, woody material, or excess sediment.
- Replace surfacing stone used for livestock crossing as needed.

REFERENCES

Alabama NRCS Conservation Practice Standards

Access Road, Code 560
Channel Bed Stabilization, Code 584
Critical Area Planting, Code 342
Fence, Code 382
Heavy Use Area Protection, Code 561
Structure for Water Control, Code 587

National NRCS Conservation Practice Standards
Aquatic Organism Passage, Code 396