

**NATURAL RESOURCES CONSERVATION SERVICE
CONSERVATION PRACTICE STANDARD
ARIZONA**

GRASSED WATERWAY

(Ac.)

CODE 412

DEFINITION

A shaped or graded channel that is established with suitable vegetation to convey surface water at a non-erosive velocity using a broad and shallow cross section to a stable outlet.

PURPOSE

- To convey runoff from terraces, diversions, or other water concentrations without causing erosion or flooding.
- To prevent gully formation.
- To protect/improve water quality.

CONDITIONS WHERE PRACTICE APPLIES

This practice is applied in areas where added water conveyance capacity and vegetative protection are needed to prevent erosion and improve runoff water quality resulting from concentrated surface flow.

CRITERIA

General Criteria Applicable to All Purposes

Conservation Practices shall be designed on an individual basis to meet site conditions and functional requirements. They shall be part of an approved and overall engineering plan for irrigation, drainage, wildlife, recreation, channel improvement, or similar purposes. Design and implementation of subsidiary components and/or structures shall meet all applicable Natural Resource Conservation Service (NRCS) conservation practice standards. The criteria for the design of any components not specifically addressed in NRCS practice standards or specifications shall be consistent with sound engineering principles and/or manufacturer recommendations.

Laws and Regulations. Plan, design, and construct grassed waterways to comply with all federal, state, *tribal* and local laws, rules, and regulations. *Laws and regulations of particular concern include those involving water rights, land use, pollution control, property easements, wetlands, preservation of cultural resources, and endangered species.*

The owner is responsible for securing necessary permits and water rights, complying with all laws and regulations, and meeting legal requirements applicable to the installation, operation, and maintenance of this practice and associated structures.

Capacity. Design the waterway to convey the peak runoff expected from the 10-year frequency, 24-hour duration storm. Increase capacity as needed to account for potential volume of sediment expected to accumulate in the waterway between planned maintenance activities. When the waterway slope is less than 1 percent, out-of-bank flow may be permitted if such flow will not cause excessive erosion. Ensure that the design capacity, at a minimum, will remove the water before crops are damaged.

Stability. Determine the minimum depth and width requirements for stability of the grassed waterway using the procedures in the NRCS National Engineering Handbook, Part 650, Engineering Field Handbook, Chapter 7, Grassed Waterways or Agricultural Research Service (ARS) Agriculture Handbook 667, Stability Design of Grass-Lined Open Channels.

Ensure that the vegetation species selected are suited to the current site conditions and intended uses. Select species that have the

capacity to achieve adequate density, height, and vigor within an appropriate time frame to stabilize the waterway.

Width. Keep the bottom width of trapezoidal waterways less than 100 feet unless multiple or divided waterways or other means are provided to control meandering of low flows.

Side slopes. Keep the side slopes flatter than a ratio of two horizontal to one vertical. Reduce the side slopes as needed to accommodate the equipment anticipated to be used for maintenance and tillage/harvesting equipment so that damage to the waterway is minimized

Depth. The capacity of the waterway must be large enough so that the water surface of the waterway is below the water surface of the tributary channel, terrace, or diversion that flows into the waterway at design flow.

Provide 0.5 foot freeboard above the designed depth when flow must be contained to prevent damage. Provide freeboard above the designed depth when the vegetation has the maximum expected retardance.

Drainage. When needed to establish or maintain vegetation on sites having prolonged flows, high water tables, or seepage problems, use Subsurface Drain (606), Underground Outlet (620), or other suitable measures in waterway designs.

Where drainage practices are not practicable or sufficient to solve these seepage problems, use conservation practice Lined Waterway or Outlet (468) in place of Grassed Waterway (412).

Outlets. Provide a stable outlet with adequate capacity. The outlet can be another vegetated channel, an earthen ditch, a grade-stabilization structure, filter strip or other suitable outlet.

Vegetative Establishment. Establish vegetation as soon as possible using the criteria listed under "Establishment of Vegetation" in the conservation practice standard Critical Area Planting (342) and/or the state planting guide.

Establish vegetation as soon as conditions permit. Use mulch anchoring, nurse crop, rock or straw or hay bale dikes, fabric or rock checks, filter fences, or runoff diversion to

protect the vegetation until it is established. Planting of a close growing crop, e.g. small grains or millet, on the contributing watershed prior to construction of the grassed waterway can also significantly reduce the flow through the waterway during establishment.

Provide livestock and vehicular crossings as necessary to prevent damage to the waterway and its vegetation.

CONSIDERATIONS

Where environmentally-sensitive areas need to be protected from dissolved contaminants, pathogens, or sediment in runoff, consider establishment of an increased width of vegetation on the waterway above the flow area. Increasing the width of the waterway above the flow area will increase filtering of sediment and pathogens as well as increase infiltration of runoff and increase nutrient removal. Where sediment control is the primary concern, consider using vegetation in the waterway which can withstand partial burial and adding sediment control measures above the waterway such as residue management. Consider increasing the channel depth and/or designing areas of increased width or decreased slope to trap and store sediment to reduce the amount of sediment that leaves a field. Be sure to provide for regular cleaning out of the waterway when trapping sediment in this manner.

Tillage and crop planting often takes place parallel to the waterway, resulting in preferential flow – and resulting erosion – along the edges of the waterway. Consider installation of measures that ensure that runoff from adjacent areas will enter the waterway. Measures such as directing spoil placement or small swales can direct this preferential flow into the grassed waterway.

Avoid areas where unsuitable plant growth limiting subsoil and/or substratum material such as salts, acidity, root restrictions, etc. may be exposed during implementation of the practice. Where areas cannot be avoided, seek recommendations from a soil scientist for improving the condition or, if not feasible consider over-cutting the waterway and add topsoil over the cut area to facilitate vegetative establishment.

Avoid or protect, if possible, important wildlife habitat, such as woody cover or wetlands when determining the location of the grassed waterway. If trees and shrubs are incorporated, they should be retained or planted in the periphery of grassed waterways so they do not interfere with hydraulic functions. Medium or tall bunch grasses and perennial forbs may also be planted along waterway margins to improve wildlife habitat. Waterways with these wildlife features are more beneficial when connecting other habitat types; e.g., riparian areas, wooded tracts and wetlands. When possible, select plant species that can serve multiple purposes, such as benefiting wildlife, while still meeting the basic criteria needed for providing a stable conveyance for runoff.

Water-tolerant vegetation may be an alternative to subsurface drains or stone center waterways on some wet sites.

Use irrigation in dry regions or supplemental irrigation as necessary to promote germination and vegetation establishment.

Wildlife habitat benefits can be provided by adding width of appropriate vegetation to the sides of the waterway. Care should be taken to avoid creating small isolated planting zones that could become population sinks where wildlife attracted to an area experience reproductive loss due to predation.

Consider including diverse legumes, forbs, and flowering plants such as milkweeds that provide pollen and nectar for native bees and other pollinators. In dry regions, these sites may be able to support flowering forbs with higher water requirements and thus provide bloom later in the summer.

The construction of a grassed waterway can disturb large areas and potentially affect cultural resources. Be sure to follow state cultural resource protection policies before construction begins.

PLANS AND SPECIFICATIONS

Prepare plans and specifications for grassed waterways that describe the requirements for applying the practice *that are guided by the National Engineering Handbook, Part 650, shall be in accordance with the National Engineering Manual, Parts 541 and 542, and*

shall be in keeping with and according to this standard. As a minimum the plans and specifications shall be prepared for each specific site and include the requirements for applying the practice to achieve the intended purpose. As a minimum this shall include the following:

- *Project location map, including section, township and range, North arrow, cooperators/owner acknowledgement and certification signature blocks, engineering job class (cover sheet);*
- *References that the owner/cooperator are responsible for all permits, rights-of-way, easements and the contact, coordination and location determination of any existing utilities or clearances (buried utility disclaimer);*
- *If applicable, a map showing the location of the practice(s) or system in reference to a known or established benchmark or reference point with the location, description and elevation clearly shown. Topographical features and/or controls shall be shown, showing tie in with existing or other planned practices;*
- *Field surveys and notes, soil investigations or geologic soil boring locations and soil classifications, earthwork or material estimates/quantities (backfill material);*
- *A plan or system overview of the layout of the grassed waterway, including direction of flow, design flow, and location of outlet; all system components, construction and installation criteria, including State and Federal [OSHA] safety requirements;*
- *Typical cross sections of the grassed waterway(s) with proper dimensioning, including, bottom width, top width, waterway depth, design flow depth, and side slopes;*
- *Plan and profile(s) views of the proposed grassed waterway(s) system and components (i.e., original ground surface, waterway invert elevations and grades [slope], water surface elevation, etc.);*
- *Disposal requirements for excess soil material, if applicable;*
- *Structural details, as needed to show construction of outlets details;*

- Site specific construction *notes, details, or specifications* that describe in writing the installation of the grassed waterway *and components*. Include specification for control of concentrated flow during construction and vegetative establishment;
- *Use Arizona Construction and Material Specifications for each item of work and material, as applicable and available. Additional specifications may need to be written to provide full material and installation instructions. Fill in blanks and add items to the specifications to make them fit the job as needed; and*
- Vegetative establishment requirements.

All designs completed by non-NRCS personal shall meet minimum State licensing board requirements and NRCS requirements and criteria as outlined in the General Manual, the National Engineering Manual (including Arizona Supplements), and the National Engineering Handbook.

OPERATION AND MAINTENANCE

Provide an operation and maintenance plan to review with the landowner. Include the following items and others as appropriate in the plan.

- Establish a maintenance program to maintain waterway capacity, vegetative cover, and outlet stability. Vegetation damaged by machinery, herbicides, or erosion must be repaired promptly.
- Protect the waterway from concentrated flow by using diversion of runoff or mechanical means of stabilization such as silt fences, mulching, hay bale barriers and etc. to stabilize grade during vegetation establishment.
- Minimize damage to vegetation by excluding livestock whenever possible, especially during wet periods. Permit grazing in the waterway only when a controlled grazing system is being implemented.
- Inspect grassed waterways regularly, especially following heavy rains. Fill, compact, and reseed damaged areas immediately. Remove sediment deposits to maintain capacity of grassed waterway.

- Avoid use of herbicides that would be harmful to the vegetation or pollinating insects in and adjacent to the waterway area.
- Avoid using waterways as turn-rows during tillage and cultivation operations.
- Mow or periodically graze vegetation to maintain capacity and reduce sediment deposition. Mowing may be appropriate to enhance wildlife values, but must be conducted to avoid peak nesting seasons and reduced winter cover.
- Apply supplemental nutrients as needed to maintain the desired species composition and stand density of the waterway.
- Control noxious weeds.
- Do not use waterways as a field road. Avoid crossing with heavy equipment when wet.
- Lift tillage equipment off the waterway when crossing and turn off chemical application equipment.
- *If fences are installed, they shall be maintained to provide warning and/or prevent unauthorized human or livestock entry.*
- *Eradicate or otherwise remove all rodents or burrowing animals that have or may potentially damage any part of the delivery or application facilities. Immediately repair any damage caused by their activity.*
- *Immediately repair any damage resulting from vandalism, vehicles, livestock or wildlife.*

REFERENCES

USDA, ARS. 1987. Stability design of grass-lined open channels. Agriculture Handbook 667.

USDA, NRCS. 2007. National Engineering Handbook, Part 650, Engineering Field Handbook, Chap. 7, Grassed waterways.