

## NATURAL RESOURCES CONSERVATION SERVICE

### CONSERVATION PRACTICE STANDARD

## DIVERSION

(Feet)

CODE 362

#### DEFINITION

A channel generally constructed across the slope with a supporting ridge on the lower side.

#### PURPOSES

This practice may be applied to support one or more of the following purposes:

- Break up concentrations of water on long slopes, on undulating land surfaces, and on land that is generally considered too flat or irregular for terracing.
- Divert water away from farmsteads, agricultural waste systems, and other improvements.
- Collect or direct water for storage, water-spreading or water-harvesting systems.
- Protect terrace systems by diverting water from the top terrace where topography, land use, or land ownership prevents terracing the land above.
- Intercept surface and shallow subsurface flow.
- Reduce runoff damages from upland runoff.
- Reduce erosion and runoff on urban or developing areas and at construction or mining sites.
- Divert water away from active gullies or critically eroding areas.

- Supplement water management on conservation cropping or stripcropping systems.

#### CONDITIONS WHERE PRACTICE APPLIES

This practice applies to all land uses where surface runoff water control and/or management are needed and where soils and topography are such that the diversion can be constructed and a suitable outlet is available or can be provided.

#### CRITERIA

##### General Criteria Applicable to All Purposes

Use of this standard requires compliance with all applicable federal, state, and local laws and regulations.

**Capacity.** Diversions used as temporary measures with an expected life span of less than 2 years will have a minimum capacity for the peak discharge from the 2-year frequency, 24-hour duration storm.

Diversions that protect agricultural land will have a minimum capacity for the peak discharge from a 10-year frequency, 24-hour duration storm.

Diversions designed to protect areas such as urban areas, buildings, roads, and animal waste management systems will have a minimum capacity for the peak discharge from a storm frequency consistent with the hazard involved but not less than a 25-year frequency, 24-hour duration storm. Freeboard will be not less than 0.3 ft.

**Conservation practice standards are reviewed periodically, and updated if needed. To obtain the current version of this standard, contact the Natural Resources Conservation Service State Office, or download it from the Field Office Technical Guide for your State.**

Design depth is the channel storm flow depth plus freeboard.

**Cross section.** The channel may be parabolic, V-shaped, or trapezoidal. The diversion will be designed to have stable side slopes.

The ridge will have a minimum top width of 4 feet at the design depth with the following exception: The ridge top width may be 3 feet at design depth for diversions with less than 10 acres of drainage area above cropland, pastureland, or woodland.

The ridge height will include an adequate settlement factor, with a minimum of 10%.

The top of the constructed ridge at any point will not be lower than the design depth plus the specified overfill for settlement.

The design depth at culvert crossings will be the culvert headwater depth for the design storm plus freeboard.

**Stability and Capacity.** Channel grades may be uniform or variable. Minimum depth and width requirements for channel stability will be determined using the procedures in the NRCS Engineering Field Handbook (EFH) Part 650, Chapter 9, or Agricultural Research Service (ARS) Agricultural Handbook 667, Stability Design of Grass-Lined Open Channels (Sept. 1987); or other equivalent methods.

When a retardance class method is used to determine capacity by the equation:

$$Q = AV,$$

(Q = Capacity; A = Area; V = Velocity)

and the velocity (V) is calculated by using Manning's equation, the highest expected value of "n" will be used.

**Location.** The outlet conditions, topography, land use, cultural operations, cultural resources, and soil type will determine the location of the diversion.

**Protection against sedimentation.** Diversions normally should not be used below high sediment producing areas. When they are, a practice or combination of practices needed to prevent damaging accumulations of sediment in the channel will be installed. This may include practices such as land treatment erosion control practices, cultural or tillage practices, vegetated filter strip, or structural measures.

Install practices in conjunction with or before the diversion construction.

If movement of sediment into the channel is a problem, the design will include extra capacity for sediment or periodic removal as outlined in the operation and maintenance plan.

**Outlets.** Each diversion must have a safe and stable outlet with adequate capacity. The outlet may be a grassed waterway, a lined waterway, a vegetated or paved area, a grade stabilization structure, an underground outlet, a stable watercourse, a sediment basin, or a combination of these practices. The outlet must convey runoff to a point where outflow will not cause damage. Vegetative outlets will be installed and established before diversion construction to insure establishment of vegetative cover in the outlet channel.

The release rate of an underground outlet, when combined with storage, will be such that the design storm runoff will not overtop the diversion ridge.

To prevent the diversion from overtopping, the designed outflow capacity of the outlet(s) must be achieved at, or below, the design depth of the diversion at their junction.

**Vegetative Establishment.** Diversions will be vegetated according to Indiana (IN) Field Office Technical Guide (FOTG) Standard (342) Critical Area Planting. Species selected will be suited to the site conditions and intended uses. Selected species will have the capacity to achieve adequate density, height, and vigor within an appropriate time frame to stabilize the diversion.

Native plant species will be used whenever possible. Known invasive species will not be used.

Establish vegetation as soon as conditions permit. Use mulch anchoring, nurse crop, rock, straw or hay bale dikes, fabric checks, filter fences, or runoff diversion to protect the vegetation until it is established. Planting of a close growing crop, e.g. small grains or millet, on the contributing watershed prior to construction of the diversion can significantly reduce the flow through the diversion during establishment.

**Lining.** If the soils or climatic conditions preclude the use of vegetation for erosion

protection, non-vegetative linings such as concrete, gravel, rock riprap, cellular block, or other approved manufactured lining systems may be used.

Liners will be designed according to IN FOTG Standard (468) Lined Waterway or Outlet.

### **CONSIDERATIONS**

A diversion in a cultivated field should be aligned and spaced from other structures or practices to permit use of modern farming equipment. The side slope lengths should be sized to fit equipment widths when cropped.

At non-cropland sites, consider planting native vegetation in areas disturbed due to construction.

To reduce the risk of vegetative failure use mulch or erosion control blankets to protect the soil until vegetation is established. Refer to IN FOTG Standard (484) Mulching for guidance on materials, quantities and techniques for mulching and erosion control blankets.

Maximize wetland functions and values with the diversion design. Minimize adverse effects to existing wetland functions and values. Diversion of upland water to prevent entry into a wetland may convert a wetland by changing the hydrology. Any construction activities should minimize disturbance to wildlife habitat. Opportunities should be explored to restore and improve wildlife habitat, including habitat for threatened, endangered, and other species of concern.

For vegetated diversions, avoid areas where unsuitable subsurface, subsoil, substratum material that limits plant growth such as salts, acidity, root restrictions, etc., may be exposed during implementation of the practice. Where these areas cannot be avoided, seek recommendations from a soil scientist for ameliorating the condition or, if not feasible consider stock piling the topsoil, over-cutting the diversion and replace the topsoil over the cut area to facilitate vegetative establishment.

### **PLANS AND SPECIFICATIONS**

Prepare plans and specifications for diversions that describe the requirements for applying the practice according to this

standard. As a minimum the plans and specifications will include:

- A plan view of the layout of the diversion.
- Typical cross sections of the diversion(s).
- Profile(s) of the diversion(s).
- Disposal requirements for excess soil material.
- Site specific construction specifications that describe the installation of the diversion. Include specification for control of concentrated flow during construction and vegetative establishment.
- Vegetative establishment requirements.

### **OPERATION AND MAINTENANCE**

An operation and maintenance plan will be prepared for use by the client. The plan will include specific instructions for maintaining diversion capacity, storage, ridge height, and outlets.

The minimum requirements to be addressed in the operation and maintenance plan are:

1. Provide periodic inspections, especially immediately following significant storms.
2. Promptly repair or replace damaged components of the diversion as necessary.
3. Maintain diversion capacity, ridge height, and outlet elevations especially if high sediment yielding areas are in the drainage area above the diversion. Establish necessary clean-out requirements.
4. Each inlet for underground outlets must be kept clean and sediment buildup redistributed so that the inlet is at the lowest point. Inlets damaged by farm machinery must be replaced or repaired immediately.
5. Redistribute sediment as necessary to maintain the capacity of the diversion.
6. Maintain vegetation and trees and control brush by hand, chemical and/or mechanical means. Maintenance of vegetation will be scheduled outside of the primary nesting season for grassland birds.

7. Control pests that will interfere with the timely establishment of vegetation
8. Keep machinery away from steep sloped ridges. Keep equipment operators informed of all potential hazards.
9. Do not graze diversion during establishment and when soil conditions are wet.
10. Protect diversion from damage by farm equipment and vehicles. Do not use diversions as a roadway and practice care when crossing to prevent tillage marks or wheel tracks.
11. Mow the diversion as needed to maintain a healthy, vigorous sod. Time the first mowing after the primary nesting season (after July 31). Remove excess top growth. Do not burn or overgraze.

#### **REFERENCES**

USDA, ARS. 1987. Stability design of grass-lined open channels. Agriculture Handbook 667.

USDA, NRCS. National Engineering Handbook, Part 650, Engineering Field Handbook, Chap. 9, Diversion.