Figure P-4 – RUSLE "P" Subfactor Adjustment for Contouring and Stripcropping



Applicable Slope Range		
Rill/Interrill Ratio		
Low	Medium	High
0.2–10%	0.2–4.0%	0.2–1.5%

RUSLE Ver 1.04 (6/16/94)

Figure P-4 – RUSLE "P" Subfactor Adjustment for Contouring and Stripcropping
(continued)

Applicable Slope Range		
Rill/Interrill Ratio		
Low	Medium	High
11–60%	4.1–12%	1.6–4.5%
0.2–60% for all ratios where erosion is dominated by runoff on thawing soils.		

RUSLE Ver 1.04 (6/16/94)



Figure P-4 – RUSLE "P" Subfactor Adjustment for Contouring and Stripcropping
(continued)