

**NATURAL RESOURCES CONSERVATION SERVICE
CONSERVATION PRACTICE STANDARD**

GRASSED WATERWAY

(Ac.)

CODE 412

DEFINITION

A shaped or graded channel that is established with suitable vegetation to convey surface water at a non-erosive velocity using a broad and shallow cross section to a stable outlet.

PURPOSE

- To convey runoff from terraces, diversions, or other water concentrations without causing erosion or flooding.
- To prevent gully formation.
- To protect/improve water quality.

CONDITIONS WHERE PRACTICE APPLIES

This practice is applied in areas where added water conveyance capacity and vegetative protection are needed to prevent erosion and improve runoff water quality resulting from concentrated surface flow.

Grassed waterway shall not be installed where it would destroy important woody wildlife cover and where the present watercourse has little or no erosion. When encountered, wetlands will be treated in accordance with current NRCS wetlands policy. Refer to NRCS booklet "Wetland Types in Missouri," or Fish and Wildlife Circular 39 for classification.

Waterway reaches or outlets requiring permanent protective linings shall be designed in accordance with Conservation Practice Standard (468) Lined Waterway or Outlet.

CRITERIA

General Criteria Applicable to All Purposes

Plan, design, and construct grassed waterways to comply with all Federal, state, and local laws and regulations. The construction of a grassed waterway can disturb large areas and

potentially affect cultural resources. Be sure to follow state cultural resource protection policies before construction begins.

Capacity. Design the waterway to convey the peak runoff expected from the 10-year frequency, 24-hour duration storm. Increase capacity as needed to account for potential volume of sediment expected to accumulate in the waterway between planned maintenance activities. When the waterway slope is less than 1 percent, out-of-bank flow may be permitted if such flow will not cause excessive erosion. Ensure that the design capacity, at a minimum, will remove the water before crops are damaged. Use appropriate drainage curve from the Missouri Supplement to National Engineering Handbook (NEH), Part 650, Engineering Field Handbook (EFH), Chapter 14, for minimum waterway capacity when out-of-bank flow is allowed.

Stability. Determine the minimum depth and width requirements for stability of the grassed waterway using the procedures in the NRCS National Engineering Handbook, Part 650, Engineering Field Handbook, Chapter 7, Grassed Waterways or Agricultural Research Service (ARS) Agriculture Handbook 667, Stability Design of Grass-Lined Open Channels. Minimum design velocity should be 1.5 feet per second to limit sediment deposition where sediment load is a concern.

Ensure that the vegetation species selected are suited to the current site conditions and intended uses. Select species that have the capacity to achieve adequate density, height, and vigor within an appropriate time frame to stabilize the waterway.

Cross section. Vegetated waterways may be either parabolic or trapezoidal in shape. The waterway shall be divided into design reaches as applicable. The channel cross section shall

Conservation practice standards are reviewed periodically, and updated if needed. To obtain the current version of this standard, contact the Natural Resource Conservation Service or download the standard from the electronic Field Office Technical Guide for Missouri.

**NRCS MOFOTG
December 2015**

412-2 GRASSED WATERWAY

be adjusted to account for changes in flowline grade or increase in drainage area.

Width. Keep the bottom width of trapezoidal waterways less than 50 feet unless multiple or divided waterways or other means are provided to control meandering of low flows.

Side slopes. Keep the side slopes flatter than a ratio of four (4) horizontal to one vertical. Reduce the side slopes as needed to accommodate the equipment anticipated to be used for maintenance and tillage/harvesting equipment so that damage to the waterway is minimized.

Permanent earth side dikes, when used, shall be of proper height to provide the design depth of the waterway. These dikes shall have a top width of at least 1 foot and side slopes of 4 (H):1 (V) or flatter. Do not allow side dikes to pond water and damage vegetation or crops.

Depth. The capacity of the waterway must be large enough so that the water surface of the waterway is below the water surface of the tributary channel, terrace, or diversion that flows into the waterway at design flow. A minimum of 0.3 foot drop shall be provided from the terrace or diversion channel flowline to the waterway channel flowline.

Provide 0.5 foot freeboard above the designed depth when flow must be contained to prevent damage to adjacent structures or high value crops. Provide freeboard above the designed depth when the vegetation has the maximum expected retardance.

Drainage. When needed to establish or maintain vegetation on sites having prolonged flows, high water tables, or seepage problems, use Subsurface Drain (606), Underground Outlet (620), or other suitable measures in waterway designs. Refer to Missouri Supplement to National Engineering Handbook (NEH), Part 650, Engineering Field Handbook (EFH), Chapter 7 Missouri Supplement for subsurface drain design criteria.

Where drainage practices are not practicable or sufficient to solve these seepage problems, use conservation practice Lined Waterway or Outlet (468) in place of Grassed Waterway (412).

Side dikes. Temporary earth side dikes may be installed, when required, to protect a new

waterway from erosion due to runoff from adjacent areas. These dikes shall be shown on the drawings as 1 foot or less in height unless design calculations indicate dikes of greater height are needed. All temporary dikes over 1 foot in height shall be designated on the drawings and documentation for the higher dike recorded in the design file. The higher dikes shall only be required on that portion of the waterway where they are justified. Producers may choose to construct dikes over 1 foot in height for their convenience. Temporary dikes shall be removed when vegetation in the waterway becomes established.

Outlets. Provide a stable outlet with adequate capacity. The outlet can be another vegetated channel, an earthen ditch, a grade-stabilization structure, filter strip or other suitable outlet.

Vegetative Establishment. Establish vegetation as soon as possible using the criteria listed under "Establishment of Vegetation" in the conservation practice standard Critical Area Planting (342) and/or the state planting guide.

Establish vegetation as soon as conditions permit. Use mulch anchoring, nurse crop, rock or straw or hay bale dikes, fabric or rock checks, filter fences, or runoff diversion to protect the vegetation until it is established. Planting of a close growing crop, e.g. small grains or millet, on the contributing watershed prior to construction of the grassed waterway can also significantly reduce the flow through the waterway during establishment.

Provide livestock and vehicular crossings as necessary to prevent damage to the waterway and its vegetation.

CONSIDERATIONS

Where environmentally-sensitive areas need to be protected from dissolved contaminants, pathogens, or sediment in runoff, consider establishment of an increased width of vegetation on the waterway above the flow area. Increasing the width of the waterway above the flow area will increase filtering of sediment and pathogens as well as increase infiltration of runoff and increase nutrient removal. Where sediment control is the primary concern, consider using vegetation in the waterway which can withstand partial burial and adding sediment control measures above the

waterway such as residue management. Consider increasing the channel depth and/or designing areas of increased width or decreased slope to trap and store sediment to reduce the amount of sediment that leaves a field. Be sure to provide for regular cleaning out of the waterway when trapping sediment in this manner.

Karst systems provide unique habitat and should be avoided as outlets. If necessary to outlet to a karst system careful environmental evaluation is needed.

Tillage and crop planting often takes place parallel to the waterway, resulting in preferential flow – and resulting erosion – along the edges of the waterway. Consider installation of measures that ensure that runoff from adjacent areas will enter the waterway. Measures such as directing spoil placement or small swales can direct this preferential flow into the grassed waterway.

Avoid areas where unsuitable plant growth limiting subsoil and/or substratum material such as salts, acidity, root restrictions, etc. may be exposed during implementation of the practice. Where areas cannot be avoided, seek recommendations from a soil scientist for improving the condition or, if not feasible consider over-cutting the waterway and add topsoil over the cut area to facilitate vegetative establishment.

Avoid or protect, if possible, important wildlife habitat, such as woody cover or wetlands when determining the location of the grassed waterway. If trees and shrubs are incorporated, they should be retained or planted in the periphery of grassed waterways so they do not interfere with hydraulic functions. Medium or tall bunch grasses and perennial forbs may also be planted along waterway margins to improve wildlife habitat. Waterways with these wildlife features are more beneficial when connecting other habitat types; e.g., riparian areas, wooded tracts and wetlands. When possible, select plant species that can serve multiple purposes, such as benefiting wildlife, while still meeting the basic criteria needed for providing a stable conveyance for runoff.

Water-tolerant vegetation may be an alternative to subsurface drains or stone center waterways on some wet sites.

Use irrigation in dry regions or supplemental irrigation as necessary to promote germination and vegetation establishment.

Wildlife habitat benefits can be provided by adding width of appropriate vegetation to the sides of the waterway. Care should be taken to avoid creating small isolated planting zones that could become population sinks where wildlife attracted to an area experience reproductive loss due to predation.

Consider including diverse legumes, forbs, and flowering plants such as milkweeds that provide pollen and nectar for native bees and other pollinators. In dry regions, these sites may be able to support flowering forbs with higher water requirements and thus provide bloom later in the summer

PLANS AND SPECIFICATIONS

Prepare plans and specifications for grassed waterways that describe the requirements for applying the practice according to this standard. As a minimum include:

- A plan view of the layout of the grassed waterway.
- Typical cross sections of the grassed waterway(s).
- Profile(s) of the grassed waterway(s).
- Disposal requirements for excess soil material.
- Site specific construction specifications that describe in writing the installation of the grassed waterway. Include specification for control of concentrated flow during construction and vegetative establishment.
- Vegetative establishment requirements.

OPERATION AND MAINTENANCE

Provide an operation and maintenance plan to review with the landowner. University of Missouri Agricultural Guide 1504 "Maintaining Grassed Waterways" provides information on the maintenance of grassed waterways. Include the following items and others as appropriate in the plan.

- Establish a maintenance program to maintain waterway capacity, vegetative cover, and outlet stability. Vegetation

412-4 GRASSED WATERWAY

damaged by machinery, herbicides, or erosion must be repaired promptly.

- Protect the waterway from concentrated flow by using diversion of runoff or mechanical means of stabilization such as silt fences, mulching, hay bale barriers and etc. to stabilize grade during vegetation establishment.
- Minimize damage to vegetation by excluding livestock whenever possible, especially during wet periods. Permit grazing in the waterway only when a controlled grazing system is being implemented.
- Inspect grassed waterways regularly, especially following heavy rains. Fill, compact, and reseed damaged areas immediately. Remove sediment deposits to maintain capacity of grassed waterway.
- Avoid use of herbicides that would be harmful to the vegetation or pollinating insects in and adjacent to the waterway area. Apply all herbicides according to label requirements.
- Avoid using waterways as turn-rows during tillage and cultivation operations.

- Mow or periodically graze vegetation to maintain capacity and reduce sediment deposition. Mowing may be appropriate to enhance wildlife values, but must be conducted to avoid peak nesting seasons and reduced winter cover.
- Apply supplemental nutrients as needed to maintain the desired species composition and stand density of the waterway.
- Control noxious weeds.
- Do not use waterways as a field road. Avoid crossing with heavy equipment when wet.
- Lift tillage equipment off the waterway when crossing and turn off chemical application equipment.

REFERENCES

USDA, ARS. 1987. Stability design of grass-lined open channels. Agriculture Handbook 667.

USDA, NRCS. 2007. National Engineering Handbook, Part 650, Engineering Field Handbook, Chap. 7, Grassed waterways

University of Missouri Agricultural Guide 1504 "Maintaining Grassed Waterways."