



Natural Resources Conservation Service

CONSERVATION PRACTICE STANDARD

WELL DECOMMISSIONING

CODE 351

(no)

DEFINITION

The sealing and permanent closure of an inactive, abandoned, or unusable water or monitoring well.

PURPOSE

A well is decommissioned to achieve one or more of the following purposes:

- Remove a water or monitoring well from active use when it is no longer needed, it cannot be rehabilitated, or it has failed structurally.
- Remove a monitoring well from use when it is no longer capable of providing representative samples or it is providing unreliable samples.
- Eliminate a physical hazard to people, animals, and farm machinery and prevent entry of animals, debris, or other foreign substances.
- Prevent contamination of groundwater by surface water inflow.
- Restore the natural hydrogeologic conditions, to the extent possible, by preventing vertical or lateral cross- contamination or commingling of groundwaters between separate water- bearing zones.
- Eliminate the possibility of repurposing the well.
- Allow for future alternative use or management of the site

CONDITIONS WHERE PRACTICE APPLIES

This practice applies to any water well or monitoring well selected for decommissioning.

CRITERIA

General Criteria Applicable to All Purposes

A certified well contractor must be used to abandon all wells. The well abandonment procedures outlined in Title 15A NCAC, Chapter 2C.0113 shall be followed by the contractor. Within 30 days after the completion of the abandonment of the well, form GW-30 shall be completed by the contractor and submitted to NC Department of Environmental and Natural Resources (NCDENR), Division of Water Quality, and a copy shall be provided to the NRCS Field Office.

Data collection

Collect and review all as-built construction documents, maintenance records, geological information, and other available data for the well(s). Include this information in the decommissioning plan.

Well preparation

Clear the well of all pumping equipment, valves, pipelines, grease, oil, scum, debris, and other foreign material. To the extent practicable, remove all casings, liners, and screens. Remove casing by either pulling or overdrilling (over-reaming) in accordance with guidance in ASTM D5299, "Standard Guide for

Decommissioning of Groundwater Wells, Vadose Zone Monitoring Devices, Boreholes, and Other Devices for Environmental Activities.”

If some or all of the casing resists removal by pulling or overdrilling, it must be ripped, perforated, or cut off below the ground surface. For the cut-off depth, use the greater of two feet, the maximum potential depth for frost penetration, or the depth of any other near-surface soil fracturing process (such as desiccation).

Sealing materials

Sealing materials must conform to the characteristics listed in ASTM

The quality of the water used for mixing with sealing materials must meet or exceed criteria provided in ASTM D5299.

Fill (plugging) materials

Select fill materials that are free of clay, silt, and organic and foreign matter. Select a soil gradation and a filling process that will not cause bridging during installation.

Plugging and sealing procedures

Do not place sealing and fill materials until after completion of the disinfection process, if conducted.

The first layer of fill material will be placed in the bottom of the well and will extend upward to a point that is no less than one foot above the top of the lowest water-bearing zone.

Place sealing material in a layer no less than one-foot thick above the top of the first layer of fill material. Sealing materials are used to restrict vertical movement of water and to prevent comingling of waters from different production zones. Install an alternating sequence of one-foot of sealing material and a maximum of 10 feet of fill material throughout the remaining well column. If another water-bearing zone is encountered, adjust the spacing of the fill layers so that the zone is sealed. Fill the borehole to a point that is two feet from the ground surface or to the top of the cutoff casing, whichever is greater. The last layer must be a sealing layer.

Use installation methods that avoid segregation, dilution, or bridging of the fill or sealing material.

For wells greater than 30 inches in diameter, place and compact backfill in a manner that minimizes segregation and bulking and prevents surface subsidence.

Casings grouted-in-place

Use a pressurized grouting procedure that will completely fill and seal all open spaces in the annulus. Acceptable grout sealant includes a combination of cement, sand, or bentonite that conforms to guidance provided in ASTM D5299.

If casings are within a collapsing formation, conduct the grouting procedures concurrently D5299. Sealing materials do not require disinfection. Select sealing materials that have an in-place hydraulic conductivity equivalent to or less than the ground surface soil surrounding the well head.

with removal of the casing so that the bottom of the casing remains submerged in the grout.

Well-head seal

Seal the interval between the ground surface and the top of the cut-off casing or last sealed layer with materials that conform to guidance in ASTM D5299. These materials may be an extension of the sealing materials used below this depth.

Mound the well-head seal about the ground surface. Grade the ground surface at the well-head in a manner that prevents ponding of surface water at the well-head.

Control of artesian pressure

If a well is under artesian pressure (flowing or not flowing), maintain a sufficiently high grout pressure to counteract the artesian pressure until initial grout set occurs. Use procedures for balancing pressures during grouting operations given in ASTM D5299.

Safety

The contractor responsible for decommissioning of the well shall provide the necessary safety measures to maintain safe working conditions around the well.

CONSIDERATIONS

If allowed by State regulations, fill materials, such as sand, pea gravel, sand-gravel mix, crushed rock, or agricultural lime, can be used to fill the well provided that the zones of sealing material conform to requirements in ASTM D5299.

If feasible, consider adding a metal “target” to the top 3 inches of the well-head seal so that the decommissioned well may be easily located with a metal detector.

Before sealing the well, consider bringing the entire column of well water to an available chlorine concentration of no less than 50 ppm, or use the greatest concentration specified by government authority. Agitate the well water and keep the solution undisturbed for no less than 12 hours to assure complete disinfection.

PLANS AND SPECIFICATIONS

Prepare plans and specifications for decommissioning a well that describe the requirements for applying the practice to achieve its intended purposes. Make a record of the installation of this practice that includes the following:

- Location of the decommissioned well by Global Positioning System (GPS), latitude/longitude, or other georeferencing convention, of such precision that allows the ready location of the site
- Date of completion of well decommissioning
- Name and address of landowner
- Name, title, and address of person responsible for well decommissioning
- Total depth of well
- Length of casing prior to decommissioning
- Length of casing removed or length of casing cut off below ground level
- Lengths of casing ripped or perforated and the method used
- Inside diameter of well bore or casing
- Type or schedule of casing material (e.g., standard weight steel, or PVC Sch-80)
- Static water level measured from ground surface prior to decommissioning
- Photographs before and after decommissioning
- Types of materials used for filling and sealing, quantities used, depth intervals for installation of each type of material, and the placement method used
- Detailed documentation of all other information pertinent to site conditions and other problems encountered during decommissioning.
- Diagram of the well (to scale) showing well construction details, static water level, and placement of fill and plugging materials.

OPERATION AND MAINTENANCE

Inspect the practice site periodically to ensure there is no ground settlement, erosion, or other disturbance. Maintain the site in a manner that prevents ponding or surface runoff toward the site

REFERENCES

American Society for Testing and Materials, D5299, "Standard Guide for Decommissioning of Groundwater Wells, Vadose Zone Monitoring Devices, Boreholes, and Other Devices for Environmental Activities." ASTM International. 100 Barr Harbour Dr., P.O. Box C-700, West Conshohocken, PA.