

## **Natural Resources Conservation Service**

## CONSERVATION PRACTICE STANDARD

# POND SEALING OR LINING - CONCRETE

## **CODE 522**

(sf)

## **DEFINITION**

A liner for an impoundment constructed using reinforced or nonreinforced concrete.

#### **PURPOSE**

This practice is used to accomplish one or more of the following purposes-

 This practice is installed to reduce seepage losses from impoundments constructed for water conservation and environmental protection

#### **CONDITIONS WHERE PRACTICE APPLIES**

This practice applies where—

- In-place natural soils have excessive seepage rates.
- Construction of a compacted soil liner is not feasible with available soils.
- Use of impoundment requires concrete both as a liner and a protective subgrade cover.

## **CRITERIA**

#### General Criteria Applicable to All Purposes

Select the concrete liner design for either 'reduced seepage' or 'liquid tight' criteria, depending on the site conditions and management needs. *Design concrete liners for waste storage facilities as "Liquid Tight".* 

#### Liquid Tight

Where liquid tightness is required to provide an additional level of protection for geologic concerns, groundwater resources and risk factors as described in the Agricultural Waste Management Field Handbook (AWMFH), Chapter 10, building code requirements must be one of the following:

- Structural Engineering, NRCS National Engineering Manual (NEM) Part 536, Structural Engineering.
- Requirements for Environmental Concrete Structures, Slabs-on-Soil, American Concrete Institute (ACI) 350 Appendix H.
  - Minimum f'c = 4000 psi
  - Maximum w/c = 0.45
  - Minimum reinforcing ratio in both orthogonal directions shall be 0.005 (0.5%) for slabs with cold joints spaced 40' and greater. Other ratios according to Table 1.

NRCS reviews and periodically updates conservation practice standards. To obtain the current version of this standard, contact your Natural Resources Conservation Service State office or visit the Field Office Technical Guide online by going to the NRCS website at <a href="https://www.nrcs.usda.gov/">https://www.nrcs.usda.gov/</a> and type FOTG in the search field.

Table 1 Minimum Temperature and Shrinkage and Temperature Reinforcement for Environmental Structures

Length between Movement Joints	Minimum Shrinkage and Temperature Reinforcement Ratio	
(Feet)	Grade 40	Grade 60
Less than 20	0.0030	0.0030
20 to less than 30	0.0040	0.0030
30 to less than 40	0.0050	0.0040
40 and greater	0.0060*	0.0050*

<sup>\*</sup> To be used when no movement joints are provided unless analysis indicates a greater amount is required.

- Maximum spacing of deformed bars shall be the lessor of 12 inches or two times the slab thickness.
- Maximum wire spacing of WWF shall be 4 inches.
- Slabs shall be placed in sections as large as possible to limit the number of cold joints. Dry and temperature shrinkage shall be considered.
- All cold joints shall have an approved waterstop, installed according to the manufacturer's instructions. Ensure minimum concrete cover requirements are met.

## Reduced Seepage

Where liquid tightness is not required, building code requirements must be one of the following:

- ACI 318, Building Code Requirements for Reinforced Concrete, ACI.
- ACI 330R, Guide for the Design and Construction of Concrete Parking Lots, ACI.
- ACI 360R, Guide to Design of Slabs-on-Ground, ACI.

#### **Construction Joints**

Design construction and isolation joints to meet the appropriate ACI code specified above. Protrusions through the liner, such as pipes, must be properly sealed. *For waste storage facilities install waterstop at all joints.* 

### Side Slopes

Side slopes shall be 2.5 horizontal to 1 vertical or flatter. Design side slopes of the pond or impoundment to be stable during construction and throughout the service life of the structure. Proportion the concrete mixture for a sufficiently stiff mix that can be installed on the slope without slumping or bulging.

## Foundation and Liner Protection

For waste storage impoundments, design foundation conditions for concrete liners, including the location and proximity of groundwater and bedrock, in accordance with Conservation Practice Standard Waste Storage Facility (Code 313).

### **CONSIDERATIONS**

Consider texturing concrete surfaces to provide traction for rubber-tired equipment.

#### PLANS AND SPECIFICATIONS

Prepare plans and specifications for a concrete liner for a pond or a waste storage impoundment that describe the requirements for applying the practice to achieve its intended purpose. As a minimum, include—

Soils investigation, including subgrade.

- · Concrete and reinforcing requirements.
- Quantities of concrete and reinforcement as specified.
- Subgrade preparation, materials and compaction.
- · Construction and material specifications.
- · Safety requirements.

### **OPERATION AND MAINTENANCE**

Maintenance activities required for this practice consist of those operations necessary to prevent and/or repair damage to the concrete liner. This includes, but is not limited to—

- Visually inspecting liner annually.
- Excluding animals.
- · Repairing damage to concrete liner, as necessary.
- Repairing liner to its original condition.
- Preventing damage from roots of tree and large shrubs by removing such vegetation at first appearance.
- Preventing and/or repairing rodent damage to concrete subgrade.

#### **REFERENCES**

American Concrete Institute (ACI), Farmington Hills, MI

- ACI 318, Building Code Requirements for Reinforced Concrete
- ACI 330R, Guide for the Design and Construction of Concrete Parking Lots
- ACI 350, Appendix H, Requirements for Environmental Concrete Structures, Slab-on-Soil
- · ACI 360, Design of Slabs on Grade