

**NATURAL RESOURCES CONSERVATION SERVICE  
CONSERVATION PRACTICE STANDARD**

**DEEP TILLAGE**

**(Acres)  
Code 324**

**DEFINITION**

Performing tillage operations below the normal tillage depth to modify the physical or chemical properties of a soil.

**PURPOSES**

This practice may be applied as part of a conservation management system to support one or more of the following:

- Fracture restrictive soil layers.
- Bury or mix soil deposits from wind or water erosion or flood overwash.
- Reduce concentration of soil contaminants, which inhibit plant growth.

**CONDITIONS WHERE PRACTICE APPLIES**

This practice applies to land having adverse soil conditions which inhibit plant growth, such as compacted layers formed by field operations, restrictive layers such as claypans, clayey layer exposed at the surface on severely eroded soils, overwash or deposits from water erosion or flooding, or contaminants in the root zone.

This standard includes tillage operations commonly referred to as deep plowing, subsoiling, ripping, or row-till, performed from time to time below the normal tillage depth.

**CRITERIA**

**General Criteria Applicable to All Purposes**

Deep tillage operations shall be performed when soil moisture is less than 30 percent of field capacity, according to the "feel test" or other acceptable method, at the maximum depth to which the tillage will be done.

On sloping land, subsoiling must be done following the approximate contour.

**Additional Criteria to Fracture Restrictive Soil Layers**

Tillage equipment such as chisels, subsoilers, bent-leg subsoilers, or rippers, with the ability to reach the required depth shall be used. Normally on suitable soil, chiseling is applicable where restrictive soil layer is less than 16 inches deep. On suitable soil, subsoiling is applicable where restrictive soil layer is more than 16 inches deep.

The depth of tillage shall be a minimum of one inch deeper than the depth of the restrictive layer. Tillage depth should be set carefully and periodically checked to maintain this working depth. On most cropland, it is necessary to subsoil to a minimum depth of 16 to 24 inches with a maximum spacing of 5 feet.

Complete fracturing of the restrictive layer is not required. The fractured zone, as a minimum, shall be sufficient to permit root penetration below the restrictive soil layer. The fractured zone does not need to extend to the row middles and should be limited to the area near the rows.

**Additional Criteria to Bury or Mix Soil Deposits from Water Erosion or Flood Overwash**

Tillage equipment such as moldboard plows, disk plows or chisels with twisted points, with the ability to reach the required depth shall be used.

Conservation practice standards are reviewed periodically, and updated if needed. To obtain the current version of this standard, contact the Natural Resources Conservation Service.

The tillage operation shall uniformly mix soil 6" or 2 times the depth of overwash, whichever is deeper, to achieve a desired available water-holding capacity (AWC) and to break the hydrologic barrier caused by over-wash layer.

**Additional Criteria to Reduce Concentration of Soil Contaminants Which Inhibit Plant Growth**

Tillage equipment such as moldboard plows, disk plows or chisels with twisted points, with the ability to reach the required depth shall be used. On soils with a high soluble salt percentage, subsoil to a depth of less than 24 inches. This is to prevent any mixing of the highly saline layers with the upper portion of the soil so that the concentration of the contaminant is below the crop tolerance level. Crop tolerance levels shall be established in accordance with Land Grant University guidance and recommendations.

**CONSIDERATIONS**

Where restrictive layers are a concern, the effects of this practice can be enhanced by including deep rooted crops in the rotation that are able to extend to and penetrate the restrictive layer.

Research on numerous crops has shown that tillage conducted excessively deeper than the compacted layer does not promote increased yields, requires excessive amounts of tillage energy, and promotes future compaction from nearby vehicle traffic.

Reduce or control equipment traffic during periods when soils are prone to compaction and formation of tillage pans.

When infertile flood overwash is mixed with the pre-flood soil profile, the soil rebuilding process can be enhanced by additions of organic matter, such as manure or cover crops utilized as green manure. Crop rotations, tillage and planting systems, which maintain high levels of crop residues, such as no-till, can also accelerate this process.

Where the flood overwash layer is too thick to effectively mix with the pre-flood soil profile, redistribution of the overwash layer by smoothing or removal may be necessary. Generally, no more than about 6 inches of overwash can be uniformly mixed into the soil

profile using commonly available equipment. Specialized equipment may be necessary where greater depths of overwash are to be incorporated.

Where unfavorable soil materials such as high sodium, calcium, gypsum, aluminum or other undesirable materials, are within anticipated deep tillage depth and would be brought to the surface by deep tillage operations, this practice should not be applied.

Transport of sediment-borne pollutant(s) offsite can be reduced when this practice is used in a conservation management system, by reducing the concentration of pollutants in the surface layer.

To help reduce compaction, it is desirable to conduct normal tillage operations when soil moisture is less than 50 percent of field capacity. When possible harvest operations should be avoided when soil moisture is greater than 50 percent of field capacity. Field harvest haul traffic should be limited to end rows or haul roads. Compacted regions between crop rows that are not fractured can assist in supporting vehicle traffic, limiting rutting and soil compaction beneath the row.

If application of this practice will impact cultural resources (Archaeological, historic, historic landscape, or traditional cultural properties), follow NRCS national policy and State operating procedures for considering cultural resources.

**PLANS AND SPECIFICATIONS**

Specifications for establishment and operation of this practice shall be prepared for each field or treatment unit according to the Criteria, Considerations and Operations & Maintenance described in this standard.

**OPERATION AND MAINTENANCE**

Deep tillage for reduction of soil compaction shall be performed whenever compaction reoccurs.

When deep tillage has been performed to reduce the concentration of soil contaminants, the contaminate levels in the root zone shall be monitored to assist with determining when or if treatment will be reapplied.