

NATURAL RESOURCES CONSERVATION SERVICE  
VIRGINIA CONSERVATION PRACTICE STANDARD

## CHANNEL STABILIZATION

(Ft.)

CODE 584

### DEFINITION

Measure(s) used to stabilize the bed or bottom of a channel

### PURPOSE

This practice may be applied as part of a conservation management system to support one or more of the following:

- Maintain or alter channel bed elevation or gradient
- Modify sediment transport or deposition
- Manage surface water and ground water levels in floodplains, riparian areas, and wetlands.

### CONDITIONS WHERE PRACTICE APPLIES

This practice applies to the beds of existing or newly constructed channels, alluvial or non-alluvial, undergoing damaging aggradation or degradation that cannot be feasibly controlled by clearing or snagging, by the establishment of vegetative protection, by the installation of bank protection, or by the installation of upstream water control measures.

### CRITERIA

Measures shall be designed and installed according to a site-specific plan that is in compliance with federal, state, and local laws and regulations.

Improvements planned or being carried out by others shall be incorporated into the design.

The selected measures shall not result in adverse affects on the function of the stream,

the floodplain, or the stream corridor.

Effects of channel work on existing structures such as culverts, bridges, buried cables, pipelines, and irrigation flumes shall be evaluated to determine impact on their intended functions.

Measures shall be functional for the design flow and sustainable for higher flow conditions based on acceptable risk.

Measures shall be compatible with the bank or shoreline materials, water chemistry, channel hydraulics, and slope characteristics, both above and below the water line.

Flow duration, depth of inundation, buoyancy, uplift, scour, angle of attack, and stream velocity shall be included in the design. Anticipated ice action, debris impact and fluctuating water levels must also be evaluated.

Sufficient depth shall be maintained to provide adequate outlets for subsurface drains, tributary stream or ditches, or other channels.

When water surface elevations are a concern, the effects of protective measures shall not cause detrimental changes in water surface elevations.

The quantity and character of the sediments entering the reach of channel under consideration shall be analyzed on the basis of both present conditions and projected conditions caused by changes in land use or land treatment and upstream improvements or structural measures.

Measures shall be designed to maintain the appropriate sediment transport regime in order to avoid detrimental erosion or sedimentation upstream and downstream.

Channel clearing to remove stumps, fallen trees, debris, and bars shall only be done when they are causing or could cause detrimental bank erosion or structural failure. Habitat forming elements that provide cover, food, pools, and water turbulence shall be retained or replaced to the extent possible.

Spoil material from clearing, grubbing, and channel excavation shall be disposed of in a manner that will not interfere with the function of the channel and in accordance with all local, state, and federal laws and regulations.

All disturbed areas around measures shall be protected from erosion. Vegetation shall be selected that is best suited for the anticipated site conditions.

Measures applied shall seek to avoid adverse effects to endangered, threatened, and candidate species and their habitats, whenever possible.

Measures applied shall seek to avoid adverse effects to archaeological, historic, structural, and traditional cultural properties, whenever possible.

### **CONSIDERATIONS**

Consider areawide planning for proper design, function and management of protective measures where the design reach involves by multiple stakeholders.

An assessment of channel stabilization needs should be considered in sufficient detail to identify the causes contributing to the instability (e.g. watershed alterations resulting in significant modifications of discharge or sediment production). Due to the complexity of such an assessment, use of an interdisciplinary team should be considered.

When designing protective measures, consider the changes that may occur in the watershed hydrology and sedimentation over the design life of the measure.

Consider protecting side channel inlets and outlets from erosion or sedimentation.

Consider utilizing woody debris removed during construction in the overall practice design.

### **Fish and Wildlife**

Measures should consider habitat and migration needs of aquatic species.

Consider maintaining or improving the habitat value for fish and wildlife, which includes lowering or moderating water temperature, and improving water quality.

Consider opportunities to improve habitat for threatened, endangered, and other species of concern, where applicable.

### **Wetlands**

Consider maximizing adjacent wetland functions and values with the project design and minimizing adverse effects to existing wetland functions and values.

### **Social and Safety Aspects**

Consider the type of human use and the social and safety aspects when designing the protective measures. Use construction materials, grading practices, vegetation, and other site development elements that enhance aesthetics, recreational use, and maintain or complement existing landscape uses such as pedestrian paths, climate controls, and buffers. Avoid excessive disturbance and compaction of the site during installation.

Measures should be designed to minimize safety hazards to boaters, swimmers, or people using the channel.

### **PLANS AND SPECIFICATIONS**

Plans and specifications for this practice shall be prepared for specific channel reaches and field sites and shall describe the requirements for applying the practice to achieve its intended purpose(s).

### **DESIGN DATA**

1. Detailed site investigation report with supporting data including flow information, channel materials, source of channel instability (if known), land use upstream and downstream, activities in the watershed impacting the stream, etc. Include photographs.
2. Completed Environmental Evaluation (Form VA-EE-1) and subsequent requirements.

3. Soils investigation.
4. Survey and plot data: profile, cross-sections, topography, as needed.
5. Design computations, including purpose of practice and references used.
6. Plan view of site with existing and planned features, including dimensions, distances, etc.
7. Standard Cover Sheet (VA-SO-100A).
8. Materials and quantities needed. Identify borrow material and/or spoil area, as needed.
9. Vegetation and/or ground cover requirements.
10. Identification of needed Erosion & Sediment Control measures.
11. Supplemental practices required.
12. Virginia Conservation Practice Specifications (700 Series).
13. Operation and Maintenance Plan.

#### CHECK DATA

1. As-built survey.
2. As-built plans including dimensions, types and quantities of materials installed, and variations from design. Include justification for variations.
3. Locations of appurtenant practices.
4. Adequacy of vegetation and/or ground cover.
5. Complete as-built section of Cover Sheet.

#### OPERATION AND MAINTENANCE

The owner or others responsible for operating and maintaining the system shall prepare an

operation and maintenance plan. The plan shall provide specific instructions for operating and maintaining the system to insure that it functions properly. It shall also provide for periodic inspections and prompt repair or replacement of damaged components.

#### REFERENCES

USDA-Natural Resources Conservation Service. National Engineering Handbook, Part 654. Stream Restoration Design, August 2007.

USDA-Natural Resources Conservation Service. National Engineering Handbook, Part 654. Stream Restoration Design, August 2007. Technical Supplement 14 G, Grade Stabilization Techniques.

USDA-Natural Resources Conservation Service. National Engineering Handbook, Part 653. Stream Corridor Restoration: Principles, Processes, and Practices. October 1998.

USDA-Natural Resources Conservation Service. Electronic Field Office Technical Guide (eFOTG), Section IV [Online]. Available at <http://www.nrcs.usda.gov/technical/eFOTG>.

USDA-Natural Resources Conservation Service. National Engineering Handbook, Part 650. Chapter 16, Streambank and Shoreline Protection, December 1996.

USDA-Natural Resources Conservation Service. Technical Release 25, Design of Open Channels. October 1977.

USDA-Natural Resources Conservation Service. General Manual. Section 190, ECOL SCI, Part 410, Compliance with NEPA, Subparts A, B & C. Available at <http://policy.nrcs.usda.gov>.

USDA-Natural Resources Conservation Service. Virginia 700 Series Construction Specifications. [On-line]. Available at <http://www.nrcs.usda.gov/technical/eFOTG>.

Virginia Department of Environmental Quality Office of Wetlands and Water Protection. Joint Permit Application. [Online]. Available at <http://www.deq.state.va.us/wetlands/>

USDA is an equal opportunity provider and employer.