

**NATURAL RESOURCES CONSERVATION SERVICE  
CONSERVATION PRACTICE STANDARD**

**CONTOUR FARMING**

(Ac.)

**CODE 330**

**DEFINITION**

Aligning ridges, furrows, and roughness formed by tillage, planting and other operations to alter velocity and/or direction of water flow to around the hillslope.

**PURPOSE**

This practice is applied to achieve one or more of the following:

- ◆ Reduce sheet and rill erosion - Resource Concern (SOIL EROSION – Sheet, rill, & wind erosion).
- ◆ Reduce transport of sediment, other solids and the contaminants attached to them - Resource Concern (SOIL EROSION – Sheet, rill, & wind erosion).
- ◆ Reduce transport of contaminants found in solution runoff - Resource Concern (WATER QUALITY DEGRADATION – Excess nutrients in surface and ground waters; Pesticides transported to surface and ground waters; Excess pathogens and chemicals from manure, bio-solids or compost applications).
- ◆ Increase water infiltration – Resource Concern (INSUFFICIENT WATER - Inefficient Moisture Management).

**CONDITIONS WHERE PRACTICE APPLIES**

This practice applies on sloping land where crops are grown. For orchards, vineyards and nut crops use Conservation Practice Standard Contour Orchard and Other Fruit Areas (code 331). (Maine does not currently support these practices).

**CRITERIA**

**General Criteria Applicable to All Purposes**

All tillage and planting operations shall be parallel to an established marker.

Contour markers may be field boundaries, filter strips, a crop row left untilled near or on an original contour baseline, or other readily identifiable, continuous, lasting marker, provided the applicable row grade criteria are met.

Where diversions or contour buffer strips are not present, maintain contour markers on grades that, when followed during establishment of each crop, will maintain crop rows at designed grades.

**The Critical Slope Length** for contouring shall not be exceeded. (The critical slope length is determined in RUSLE2, Profile view, Supporting Practices.) If critical slope length will be exceeded, see if Contour Buffer Strips (332) will work. If necessary, install Diversions (362) or establish permanent sod beginning at or upslope from Critical Slope Length.

**Minimum Row Grade.** The crop rows shall have sufficient grade to ensure that runoff water does not pond and cause unacceptable crop damage. 1% row grade minimum is recommended for Maine unless increased infiltration is the purpose.

**Maximum Row Grade.** The maximum row grade shall not exceed one-half of the up-and-down hill slope percent used for conservation planning with a maximum 4 percent row grade.

Up to a 25% deviation from the design row grade is permitted within 150 feet of a stable outlet.

When the row grade reaches the maximum

allowable design grade, a new baseline shall be established up or down slope from the last contour line, and used for layout of the next contour pattern.

#### **Minimum Ridge Height.**

- **Row spacing greater than 10 inches.** The minimum ridge height shall be 2 inches during the period of the rotation that is most vulnerable to sheet and rill erosion. Ridge height will be determined using the current approved water erosion prediction technology (RUSLE2).
- **Row spacing 10 inches or less.** The minimum ridge height shall be one inch for close-grown crops, such as small grains. Plant height shall be at least 6 inches high and the spacing between plants within the row shall not be greater than 2 inches during the time most vulnerable to sheet and rill erosion.

The minimum ridge height criteria are not required when the Conservation Practice Standard Residue and Tillage Management – No Till (Code 329) is used on the contour and at least 50 percent surface residue cover is present between the rows after planting.

(Note: Ridge height is created by the operation of tillage and planting equipment. The greater the ridge height, the more effective the operation is in slowing overland flow. The RUSLE2 Operations database contains the ridge height value for each field operation under “Process: Disturb Surface”.)

**Stable Outlets.** Surface flow from contoured fields shall be delivered to stable outlets. Grassed waterways, water and sediment control basins, underground outlets, or other suitable practices should be used to protect areas of existing or potential concentrated flow erosion.

#### **Additional Criteria to Increase Water Infiltration**

**Row Grade.** The maximum row grade shall not exceed 0.2%. (Note that in Maine, heavy rainstorms may result in increased crop damage if water accumulates behind and then breaks through ridges.)

## **CONSIDERATIONS**

**General.** Several factors influence the effectiveness of contour farming to reduce soil erosion. These factors include: 10-year, 24-hour rainfall in inches; ridge height; row grade; slope steepness; soil hydrologic group; cover and roughness; and slope length. Cover and roughness, row grade, and ridge height can be influenced by management and provide more or less benefit depending on design.

Contour farming is most effective on slopes between 2 and 10 percent. This practice will be less effective in achieving the stated purpose(s) on slopes exceeding 10 percent and in areas with 10-year, 24-hour rainfall of about 6.5 inches.

**The practice is not well suited to rolling topography having a high degree of slope irregularity because of the difficulty meeting row grade criteria.**

This practice is most effective on slopes between 100 and 400 feet long. On slopes longer than 400 feet, the volume and velocity of overland flow exceeds the capacity of the contour ridges to contain them. Increasing residue cover and roughness will change the vegetative cover-management conditions and decrease overland flow velocities, thus increasing the slope length at which this practice is effective. Increasing roughness alone is not sufficient to produce this effect.

The closer the row grade is to the true contour, the greater the erosion reduction. “Absolute row grade” should be selected rather than “relative row grade” in the supporting practices step of RUSLE2 when designing contour strips.

Prior to design and layout, obstruction removal and changes to field boundaries or shape should be considered, where feasible, to improve the effectiveness of the practice and the ease of performing farming operations.

When the intersection of crop rows with the field edge is not perpendicular, Conservation Practice Standard Field Border (Code 386) may be needed to allow farm implements room to turn and control erosion along the field border.

If using ridge till on the contour, avoid crossing over ridged rows at correction areas because this will destroy the effectiveness of the ridges. Sod turn strips may be established if correction areas are unavoidable.

The width of correction areas, and the distance between baselines, should be adjusted for equipment operation widths.

Where contour row curvature becomes too sharp to keep machinery aligned with rows during field operations, establish sod turn strips on sharp ridge points or other odd areas as needed.

## **PLANS AND SPECIFICATIONS**

Specifications for establishment and operation of this practice shall be prepared for each field according to the Criteria, Considerations, and Operation and Maintenance described in this standard. The plans shall include, as a minimum:

- Percent land slope used for conservation planning;
- The minimum and maximum allowable row grades for the contour system (demonstrate with RUSLE2)
- A sketch map or photograph of the field showing:
  - ◊ the approximate location of the baselines used to establish the system;
  - ◊ the location of stable outlets for the system

Specifications shall be recorded using Maine's 330 Jobsheet.

## **OPERATION AND MAINTENANCE**

All tillage and planting operations shall be parallel to the established marker.

If a marker is lost, re-establish a contour baseline within the applicable criteria set forth by this standard prior to seedbed preparation for the next crop.

Farming operations should begin on the contour baselines and proceed both up and down the slope in a parallel pattern until patterns meet. Where field operations begin to converge between two non-parallel contour baselines, establish a correction area that is permanently in sod or established to an annual close-grown crop.