

CONSERVATION PRACTICE STANDARD

WELL DECOMMISSIONING

(No.)

CODE 351

DEFINITION

The sealing and permanent closure of an inactive, abandoned, or unusable water or monitoring well.

PURPOSE

A well is decommissioned to achieve one or more of the following purposes:

- Remove a water or monitoring well from active use when it is no longer needed, it cannot be rehabilitated, or it has failed structurally.
- Remove a monitoring well from use when it is no longer capable of providing representative samples or it is providing unreliable samples.
- Eliminate a physical hazard to people, animals, and farm machinery and prevent entry of animals, debris, or other foreign substances.
- Prevent contamination of groundwater by surface water inflow.
- Restore the natural hydrogeologic conditions, to the extent possible, by preventing vertical or lateral cross-contamination or commingling of groundwaters between separate water-bearing zones.
- Eliminate the possibility of repurposing the well.
- Allow for future alternative use or management of the site

CONDITIONS WHERE PRACTICE APPLIES

This practice applies to any water well or monitoring well selected for decommissioning.

This practice does not apply to wells that were used for waste disposal.

CRITERIA

General Criteria Applicable to All Purposes

Decommissioning shall be compatible with all applicable local, state, and federal requirements.

Data collection. Collect and review all as-built construction documents, maintenance records, and other available data for the well(s). Include this information in the decommissioning plan. Existing conditions shall be documented as defined in Plans and Specifications.

Well preparation. Clear the well of all pumping equipment, valves, pipelines, grease, oil, scum, debris, and other foreign material. To the extent practicable, remove all casings, liners, and screens. Remove casing by either pulling or overdrilling (over-reaming) in accordance with guidance in ASTM D5299, "Standard Guide for Decommissioning of Groundwater Wells, Vadose Zone Monitoring Devices, Boreholes, and Other Devices for Environmental Activities."

If some or all of the casing resists removal by pulling or overdrilling, it must be ripped, perforated, or cut off below the ground surface. For the cut-off depth, use the greater of two feet, the maximum potential depth for frost penetration, or the depth of any other near-surface soil fracturing process (such as desiccation).

Sealing materials. Sealing materials used in well decommissioning shall be of sufficiently low hydraulic conductivity to prevent groundwater flow vertically in the well. Sealing materials must conform to the characteristics listed in ASTM D5299. Sealing materials do not require disinfection. Select sealing materials that have an in-place hydraulic conductivity equivalent to

or less than the ground surface soil surrounding the well head.

The quality of the water used for mixing with sealing materials must meet or exceed criteria provided in ASTM D5299.

Fill (plugging) materials. Select fill materials that are free of clay, silt, and organic and foreign matter. Select a soil gradation and a filling process that will not cause bridging during installation.

Plugging and sealing procedures. Do not place sealing and fill materials until after completion of the disinfection process, if conducted.

The first layer of fill material will be placed in the bottom of the well and will extend upward to a point that is no less than one foot above the top of the lowest water-bearing zone.

Place sealing material in a layer no less than one-foot thick above the top of the first layer of fill material. Sealing materials are used to restrict vertical movement of water and to prevent commingling of waters from different production zones. Install an alternating sequence of one-foot of sealing material and a maximum of 10 feet of fill material throughout the remaining well column. If another water-bearing zone is encountered, adjust the spacing of the fill layers so that the zone is sealed. Fill the borehole to a point that is two feet from the ground surface or to the top of the cutoff casing, whichever is greater. The last layer must be a sealing layer.

Use installation methods that avoid segregation, dilution, or bridging of the fill or sealing material.

For wells greater than 30 inches in diameter, place and compact backfill in a manner that minimizes segregation and bulking and prevents surface subsidence.

Casings grouted-in-place. Use a pressurized grouting procedure that will completely fill and seal all open spaces in the annulus. Acceptable grout sealant includes a combination of cement, sand, or bentonite that conforms to guidance provided in ASTM D5299.

If casings are within a collapsing formation, conduct the grouting procedures concurrently with removal of the casing so that the bottom of the casing remains submerged in the grout.

Well-head seal. Seal the interval between the ground surface and the top of the cut-off casing

or last sealed layer with materials that conform to guidance in ASTM D5299. These materials may be an extension of the sealing materials used below this depth.

Mound the well-head seal about the ground surface. The soil material or sealing materials shall achieve an in-place hydraulic conductivity equivalent to or less than the surface soil surrounding the well. Grade the ground surface at the well-head in a manner that prevents ponding of surface water at the well-head.

Control of artesian pressure. If a well is under artesian pressure (flowing or not flowing), maintain a sufficiently high grout pressure to counteract the artesian pressure until initial grout set occurs. Use procedures for balancing pressures during grouting operations given in ASTM D5299.

CONSIDERATIONS

Consult a geologist when wells are located on difficult or unique geology that could affect proper decommissioning.

To the extent practicable, an abandoned well should be decommissioned in a manner that restores the original hydrogeologic conditions of the well site and does not preclude the use of the site from future land management practices.

All decommissioning procedures, and fill and sealing materials need to be selected with due consideration of the site-specific geological, biological, physical and climatic conditions, the chemical composition of the surrounding soil, rock and ground water at the well site, and the well's construction practices.

If allowed by State regulations, fill materials, such as sand, pea gravel, sand-gravel mix, crushed rock, or agricultural lime, can be used to fill the well provided that the zones of sealing material conform to requirements in ASTM D5299.

If feasible, consider adding a metal "target" to the top 3 inches of the well-head seal so that the decommissioned well may be easily located with a metal detector.

Before sealing the well, consider bringing the entire column of well water to an available chlorine concentration of no less than 50 ppm,

or use the greatest concentration specified by government authority. Agitate the well water and keep the solution undisturbed for no less than 12 hours to assure complete disinfection.

PLANS AND SPECIFICATIONS

Prepare plans and specifications for decommissioning a well that describe the requirements for applying the practice to achieve its intended purposes. Make a record of the installation of this practice that includes the following:

- Location of the decommissioned well by Global Positioning System (GPS), latitude/longitude, township/range, or other georeferencing convention, of such precision that allows the ready location of the site
- Date of completion of well decommissioning
- Name of landowner
- Name, title, and address of person responsible for well decommissioning
- Length of casing prior to decommissioning
- Length of casing removed or length of casing cut off below ground level
- Lengths of casing ripped or perforated and the method used
- Type or schedule of casing material (e.g., standard weight steel, or PVC Sch-80)
- Static water level measured from ground surface prior to decommissioning
- Photographs before and after decommissioning
- Types of materials used for filling and sealing, quantities used, depth intervals for installation of each type of material, and the placement method used
- Well diagram, showing depths, diameters, metal target for future location if applicable, perforations, etc.
- Detailed documentation of all other information pertinent to site conditions and other problems encountered during decommissioning.

OPERATION AND MAINTENANCE

Inspect the practice site periodically to ensure there is no ground settlement, erosion, or other disturbance. Maintain the site in a manner that prevents ponding or surface runoff toward the site

REFERENCES

American Society for Testing and Materials, D5299, "Standard Guide for Decommissioning of Groundwater Wells, Vadose Zone Monitoring Devices, Boreholes, and Other Devices for Environmental Activities." ASTM International, 100 Barr Harbour Dr., P.O. Box C-700, West Conshohocken, PA.