

NATURAL RESOURCES CONSERVATION SERVICE**CONSERVATION PRACTICE STANDARD****GRASSED WATERWAY****(AC.)****CODE 412****DEFINITION**

A shaped or graded channel that is established with suitable vegetation to convey surface water at a non-erosive velocity using a broad and shallow cross section to a stable outlet.

PURPOSE

- To convey runoff from terraces, diversions, or other water concentrations without causing erosion or flooding.
- To prevent gully formation.
- To protect/improve water quality.

CONDITIONS WHERE PRACTICE APPLIES

This practice is applied in areas where added water conveyance capacity and vegetative protection are needed to prevent erosion and improve runoff water quality resulting from concentrated surface flow.

CRITERIA**GENERAL CRITERIA APPLICABLE TO ALL PURPOSES**

Plan, design, and construct grassed waterways to comply with all federal, state, and local laws and regulations.

Grassed Waterways are typically utilized to provide outlets for terraces within a cropland field. They can also be used for small upland drainage areas in non-cropland to control erosion where there is a small concentration of water. Grassed waterways associated with cropland fields should not be planned or installed in locations where the majority of the runoff originates from beyond the field boundary unless approved by a field or zone engineer.

Capacity.

Design the waterway to convey the peak runoff expected from the 10-year frequency, 24-hour duration storm. Increase capacity as needed to account for potential volume of sediment expected to accumulate in the waterway between planned maintenance activities. When the waterway slope is less than 1 percent, out-of-bank flow may be permitted if such flow will not cause excessive erosion. Ensure that the design capacity, at a minimum, will remove the water before crops are damaged.

Minimum capacity requirements for waterways serving as outlets for level terrace systems shall be as follows: Systems of level terraces with open ends, or systems with end closures that do not impound at least the 10-year, 24-hour rainfall runoff, shall have minimum capacity equal to 50 percent of the 10-year frequency, 24-hour peak discharge of the drainage area.

For waterways that are components of a waste management system, the minimum capacity shall be that required to convey the peak discharge expected from a storm of 25-year frequency, 24 hour duration.

Guidance for determining peak runoff is provided in Texas Engineering Technical Note No. 210-18TX5, Hydrology, Estimating Runoff for Conservation Practices; Engineering Field Handbook, Chapter 2, Estimating Runoff and Peak Discharges; and Technical Release No.55, Urban Hydrology for Small Watersheds.

Stability.

Determine the minimum depth and width requirements for stability of the grassed waterway using the procedures in the NRCS National Engineering Handbook, Part 650, Engineering Field Handbook, Chapter 7, Grassed Waterways or Agricultural Research Service (ARS) Agriculture Handbook 667, Stability Design of Grass-Lined Open Channels.

Ensure that the vegetation species selected are suited to the current site conditions and intended uses. Select species that have the capacity to achieve adequate density, height, and vigor within an appropriate time frame to stabilize the waterway.

Width.

Keep the bottom width of trapezoidal waterways less than 100 feet unless multiple or divided waterways or other means are provided to control meandering of low flows.

Side slopes.

Keep the side slopes flatter than a ratio of two horizontal to one vertical. Flatten the side slopes as needed to accommodate the equipment anticipated to be used for maintenance and tillage/harvesting equipment so that damage to the waterway is minimized.

Depth.

The capacity of the waterway must be large enough so that the water surface of the waterway is below the water surface of the tributary channel, terrace, or diversion that flows into the waterway at design flow.

Provide 0.5 foot freeboard above the designed depth when flow must be contained to prevent damage. Provide freeboard above the designed depth when the vegetation has the maximum expected retardance.

Drainage.

When needed to establish or maintain vegetation on sites having prolonged flows, high water tables, or seepage problems, use Subsurface Drain (606), Underground Outlet (620), or other suitable measures in waterway designs.

Where drainage practices are not practicable or sufficient to solve these seepage problems, use conservation practice Lined Waterway or Outlet (468) in place of Grassed Waterway (412).

Outlets.

Provide a stable outlet with adequate capacity. The outlet can be another vegetated channel, an earthen ditch, a grade-stabilization structure, filter strip or other suitable outlet.

Vegetative Establishment.

Establish vegetation as soon as possible using the criteria listed under “Establishment of Vegetation” in the conservation practice standard Critical Area Planting (342) and/or the state planting guide.

If periodic saturated soil conditions are expected at the site, species selected for establishment shall be adapted to dry and saturated soil conditions.

Seedbed preparation, time of seeding, mixture rate, stabilizing crop, mulching, or mechanical means of stabilizing, fertilizer and lime requirements shall be specified for each applicable area in accordance with [Appendix 1 Critical Area Planting Standard \(342\)](#). Alternative materials, methods or planting conditions must be approved by the Zone Agronomist in writing.

Establish vegetation as soon as conditions permit. Use mulch anchoring, nurse crop, rock or straw or hay, *Hide-A-Bales*, bale dikes, fabric or rock checks, filter fences, or runoff diversion to protect the vegetation until it is established. Planting of a close growing crop, e.g. small grains or millet, on the contributing watershed prior to construction of the grassed waterway can also significantly reduce the flow through the waterway during establishment. *When temporary cover or dead litter crops are needed prior to seeding permanent cover use Critical Area Planting [Appendix 2 Critical Area Planting Standard \(342\)](#).*

Provide livestock and vehicular crossings as necessary to prevent damage to the waterway and its vegetation.

Protection Against Erosion

Perennial vegetation should be used for erosion protection in waterways. Exceptions to the use of perennial vegetation in waterways on gentle slopes (generally less than one percent) where the velocity of 2 feet per second or less for easily eroded soils, or 3 feet per second or less for erosion-resistant soils, may be treated as follows:

1. *Planted to a drilled crop (limited to species listed in appendix 2)*
2. *Tilled to eliminate vegetation where silting is a problem.*
3. *Managed by an applicable combination of a or b.*

CONSIDERATIONS

Where environmentally-sensitive areas need to be protected from dissolved contaminants, pathogens, or sediment in runoff, consider establishment of an increased width of vegetation on the waterway above the flow area. Increasing the width of the waterway above the flow area will increase filtering of sediment and pathogens as well as increase infiltration of runoff and increase nutrient removal. Where sediment control is the primary concern, consider using vegetation in the waterway which can withstand partial burial and adding sediment control measures above the waterway such as residue management. Consider increasing the channel depth and/or designing areas of increased width or decreased slope to trap and store sediment to reduce the amount of sediment that leaves a field. Be sure to provide for regular cleaning out of the waterway when trapping sediment in this manner.

Tillage and crop planting often takes place parallel to the waterway, resulting in preferential flow – and resulting erosion – along the edges of the waterway. Consider installation of measures that ensure that runoff from adjacent areas will enter the waterway. Measures such as directing spoil placement or small swales can direct this preferential flow into the grassed waterway.

Avoid areas where unsuitable plant growth limiting subsoil and/or substratum material such as salts, acidity, root restrictions, etc. may be exposed during implementation of the practice. Where areas cannot be avoided, seek recommendations from a soil scientist for improving the condition or, if not feasible consider over-cutting the waterway and add topsoil over the cut area to facilitate vegetative establishment.

Avoid or protect, if possible, important wildlife habitat, such as woody cover or wetlands when determining the location of the grassed waterway. If trees and shrubs are incorporated, they should be retained or planted in the periphery of grassed waterways so

they do not interfere with hydraulic functions. Medium or tall bunch grasses and perennial forbs may also be planted along waterway margins to improve wildlife habitat. Waterways with these wildlife features are more beneficial when connecting other habitat types; e.g., riparian areas, wooded tracts and wetlands. When possible, select plant species that can serve multiple purposes, such as benefiting wildlife, while still meeting the basic criteria needed for providing a stable conveyance for runoff.

Water-tolerant vegetation may be an alternative to subsurface drains or stone center waterways on some wet sites.

Use irrigation in dry regions or supplemental irrigation as necessary to promote germination and vegetation establishment.

Wildlife habitat benefits can be provided by adding width of appropriate vegetation to the sides of the waterway. Care should be taken to avoid creating small isolated planting zones that could become population sinks where wildlife attracted to an area experience reproductive loss due to predation.

Consider including diverse legumes, forbs, and flowering plants such as milkweeds that provide pollen and nectar for native bees and other pollinators. In dry regions, these sites may be able to support flowering forbs with higher water requirements and thus provide bloom later in the summer.

The construction of a grassed waterway can disturb large areas and potentially affect cultural resources. Be sure to follow state cultural resource protection policies before construction begins.

PLANS AND SPECIFICATIONS

Prepare plans and specifications for grassed waterways that describe the requirements for applying the practice according to this standard. As a minimum include:

1. A plan view of the layout of the grassed waterway.
2. Typical cross sections of the grassed waterway(s).
3. Profile(s) of the grassed waterway(s).
4. Disposal requirements for excess soil material.
5. Site specific construction specifications that describe in writing the installation of the grassed waterway. Include specification for control of concentrated flow during construction and vegetative establishment.
6. Vegetative establishment requirements.

OPERATION AND MAINTENANCE

Provide an operation and maintenance plan to review with the landowner. Include the following items and others as appropriate in the plan.

1. Establish a maintenance program to maintain waterway capacity, vegetative cover, and outlet stability. Vegetation damaged by machinery, herbicides, or erosion must be repaired promptly.
2. Protect the waterway from concentrated flow by using diversion of runoff or mechanical means of stabilization such as silt fences, mulching, hay bale barriers and etc. to stabilize grade during vegetation establishment.
3. Minimize damage to vegetation by excluding livestock whenever possible, especially during wet periods. Permit grazing in the waterway only when a controlled grazing system is being implemented.
4. Inspect grassed waterways regularly, especially following heavy rains. Fill, compact, and reseed damaged areas immediately. Remove sediment deposits to maintain capacity of grassed waterway.
5. Avoid use of herbicides that would be harmful to the vegetation or pollinating insects in and adjacent to the waterway area.
6. Avoid using waterways as turn-rows during tillage and cultivation operations.
7. Mow or periodically graze vegetation to maintain capacity and reduce sediment deposition. Mowing may be appropriate to enhance wildlife values, but must be conducted to avoid peak nesting seasons and reduced winter cover.
8. Apply supplemental nutrients as needed to maintain the desired species composition and stand density of the waterway.
9. Control noxious weeds.
10. Do not use waterways as a field road. Avoid crossing with heavy equipment when wet.
11. Lift tillage equipment off the waterway when crossing and turn off chemical application equipment.

REFERENCES

USDA, ARS. 1987. Stability design of grass-lined open channels. Agriculture Handbook 667.

USDA, NRCS. 2007. National Engineering Handbook, Part 650, Engineering Field Handbook, Chap. 7, Grassed waterways.

U.S. Department of Agriculture, Soil Conservation Service. 1954. Handbook of Channel Design for Soil and Water Conservation, SCS-TP-61. Washington, DC.

TEXAS, NRCS

October 2015

Critical Area Planting (342), Appendix 1, Conservation Cover

Critical Area Planting (342), Appendix 2, Dead Litter Cover

Texas Engineering Technical Note No. 210-18TX5, Hydrology, Estimating Runoff for Conservation Practices

APPROVAL AND CERTIFICATION

GRASSED WATERWAY

(AC.)

Code 412

PRACTICE STANDARD APPROVED:

/s/ JOHN MUELLER
State Conservation Engineer

November 30, 2015
Date