

**NATURAL RESOURCES CONSERVATION SERVICE**  
**CONSERVATION PRACTICE STANDARD**  
**CHANNEL STABILIZATION**

(Ft.)

CODE 584

**DEFINITION**

Measure(s) used to stabilize the bed or bottom of a channel

**PURPOSE**

This practice may be applied as part of a conservation management system to support one or more of the following:

- Maintain or alter channel bed elevation or gradient.
- Modify sediment transport or deposition
- Manage surface water and ground water levels in floodplains, riparian areas, and wetlands.

**CONDITIONS WHERE PRACTICE APPLIES**

This practice applies to the beds of existing or newly constructed channels, alluvial or non-alluvial, undergoing damaging aggradation or degradation that cannot be feasibly controlled by clearing or snagging, by the establishment of vegetative protection, by the installation of bank protection, or by the installation of upstream water control measures.

**CRITERIA**

**Federal, State and Local Laws and Permits**

***Design and construction activities shall comply with all federal, state, and local laws, rules, and regulations governing activities in or along streams, pollution abatement, health, and safety.***

***The owner or operator shall be responsible for securing all required permits or***

NRCS, NHCP  
July 2002

***approvals and for performing all planned work in accordance with such laws and regulations. NRCS employees are not to assume responsibility for procuring these permits, rights, or approvals, or for enforcing laws and regulations. NRCS may provide the landowner or operator with technical information needed to obtain the required rights or approvals to construct, operate, and maintain the practice.***

***Permits may be required from the following agencies when obstruction removal is performed within the boundaries of a stream or floodplain or if burning is required:***

- 1. US Army Corps of Engineers (USACE)***
- 2. WV Department of Natural Resources***
- 3. WV Public Lands Corporation***
- 4. US Fish and Wildlife Service***
- 5. Local, state and county ordinances***

***Work near waters where there is a present or possible presence of endangered or threatened species requires notification and collaboration with the USFWS.***

***Work in or adjacent to "Waters of the US" may require a WV Public Land Corporation Application, a Nation Wide Permit or Individual Section 404 permit from the USACE.***

***All required permits shall be approved before construction implementation.***

Measures shall be designed and installed according to a site-specific plan.

NRCS, WV  
June, 2010

Conservation practice standards are reviewed periodically, and updated if needed. To obtain the current version of this standard, contact the Natural Resources Conservation Service **State Office** or visit the **electronic Field Office Technical Guide (e-FOTG)** located on our web site. **Note: Bold italics is information added or changes made to the National Conservation Standard by WV.**

Measures to be applied shall be compatible with improvements planned or being carried out by others.

Sufficient depth shall be maintained to provide adequate outlets for subsurface drains, tributary streams or ditches, or other channels.

Effect of channel work on existing structures such as culverts, bridges, buried cables, pipelines, and irrigation flumes shall be evaluated to determine impact on their intended functions.

Measures shall be designed for flow duration, depth of inundation, buoyancy, uplift, scour, angle of attack, and stream velocity.

Measures shall be compatible with the bank or shoreline materials, water chemistry, channel hydraulics, and slope characteristics, both above and below the water line.

Measures shall be designed for anticipated ice action, debris impact and fluctuating water levels.

Spoil material from clearing, grubbing, and channel excavation shall be disposed of in a manner that will not interfere with the function of the channel and in accordance with all local, state, and federal laws and regulations.

All disturbed areas around measures shall be protected from erosion. Vegetation shall be selected that is best suited for the anticipated site conditions.

Measures applied shall seek to avoid adverse effects to endangered, threatened, and candidate species and their habitats, whenever possible.

Measures applied shall seek to avoid adverse effects to archaeological, historic, structural, and traditional cultural properties, whenever possible.

Channel clearing to remove stumps, fallen trees, debris, and bars shall only be done when they are causing or could cause detrimental bank erosion or structural failure. Habitat forming elements that provide cover, food, pools, and water turbulence shall be retained or replaced to the extent possible.

Measures shall be functional for the design flow and sustainable for higher flow conditions based on acceptable risk.

Measures shall be designed to maintain the appropriate sediment transport regime in order to avoid detrimental erosion or sedimentation upstream and downstream.

Measures shall not impair the floodplain function.

Measures shall not result in adverse affects on the function of the stream or the stream corridor.

When water surface elevations are a concern, the effects of protective measures shall not cause detrimental changes in water surface elevations.

The quantity and character of the sediments entering the reach of channel under consideration shall be analyzed on the basis of both present conditions and projected conditions caused by changes in land use or land treatment and upstream improvements or structural measures.

## CONSIDERATIONS

Consider area wide planning for proper design, function and management of protective measures where the design reach involves by multiple stakeholders.

An assessment of channel stabilization needs should be considered in sufficient detail to identify the causes contributing to the instability (e.g. watershed alterations resulting in significant modifications of discharge or sediment production). Due to the complexity of such an assessment, use of an interdisciplinary team should be considered.

When designing protective measures, consider the changes that may occur in the watershed hydrology and sedimentation over the design life of the measure.

Consider utilizing woody debris removed during construction in the overall practice design.

Measures should consider habitat and migration needs of aquatic species.

Consider maintaining or improving the habitat value for fish and wildlife, which includes lowering or moderating water temperature, and improving water quality.

Consider opportunities to improve habitat for threatened, endangered, and other species of concern, where applicable.

Consider maximizing adjacent wetland functions and values with the project design and minimizing adverse effects to existing wetland functions and values.

Consider protecting side channel inlets and outlets from erosion or sedimentation.

Consider the type of human use and the social and safety aspects when designing the protective measures. Use construction materials, grading practices, vegetation, and other site development elements that enhance aesthetics, recreational use, and maintain or complement existing landscape uses such as pedestrian paths, climate controls, and buffers. Avoid excessive disturbance and compaction of the site during installation.

Measures should be designed to minimize safety hazards to boaters, swimmers, or people using the channel.

#### **PLANS AND SPECIFICATIONS**

Plans and specifications for this practice shall be prepared for specific channel reaches and field sites and shall describe the requirements for applying the practice to achieve its intended purpose(s).

#### **OPERATION AND MAINTENANCE**

The owner or others responsible for operating and maintaining the system shall prepare an operation and maintenance plan. The plan shall provide specific instructions for operating and maintaining the system to insure that it functions properly. It shall also provide for periodic

inspections and prompt repair or replacement of damaged components.

#### **REFERENCES**

***WV5-Engineering Field Handbook, Appendix A- Quick Reference Design and Construction Support Data for Conservation Practices***

***WV e-FOTG Section IV- Practice Standards and Scope of Work such as Channel Bank Vegetation (322); Roof Runoff (558); Streambank and Shoreline Protection (580), Open Channel (582) found at <http://www.nrcs.usda.gov/technical/efotg/> (click on WV from the US map)***

***NRCS National and State Utility Safety Policy (NEM Part 503-Safety, Subpart A - Engineering Activities Affecting Utilities 503.00 through 503.06)***

***NRCS National Engineering Policy <http://policy.nrcs.usda.gov/> National Engineering Handbook (NEH) Title 210 – Section 5 – Hydraulics, Part 630 Hydraulics Part 630 Hydrology Part 650 Engineering Field Handbook Part 650, Chapter 16, Streambank and Shoreline Protection NEH-20 or WV “700” Series Specifications Title 190- Ecological Sciences; Part 601- National Cultural Resources Procedures Handbook Part 610- Environmental Compliance Handbook***